



Installation, Operation & Maintenance Instructions

1200°C Split Tube furnaces (3-zone)
types HZS & TVS

This manual is for the guidance of operators of the above Carbolite products and should be read before the furnace is connected to the electricity supply.

CONTENTS

Section	page
1.0 Introduction	2
2.0 Installation	3
3.0 Operation	5
4.0 Maintenance	7
5.0 Repairs & Replacements	8
6.0 Fault Analysis	11
7.0 Circuit Details	12
8.0 Internal supply fuses	15
9.0 Specifications	16

**Manuals are supplied separately for the furnace controllers
(and overtemperature controller when fitted).**

Please read the controller manuals before operating the furnace.

INTRODUCTION

1.1 Models in the Range

The HZS and TVS range of 1200°C split tube furnaces is available in a variety of styles and orientations. The principal varieties are:

- vertical TVS, without outer casework , optionally with a wall bracket, for customer mounting;
- vertical TVS as above, with a stand. One half of the furnace is fixed to the stand. This is known as a “near hinge” arrangement;
- vertical TVS with a “far hinge” arrangement. Both halves of the furnace hinge from the stand;
- horizontal HZS, in an outer case;
- horizontal HZS as above, but fitted to an “L-stand” which can be used in a horizontal or vertical position.

In all the above the furnace heating section and the electrical characteristics are the same.

The standard control arrangement for these 3-zone furnaces is for slave end zone controllers to follow the temperature of the main controller. The end zones are quite short – 150mm in all models. There are optional alternatives to this control arrangement, including independent control of the heating zones, and the furnaces may also be ordered with equal zone lengths. Note that the original design intent in these “3-zone” models is to achieve an extended uniform single zone. When independent control is fitted, some temperature difference can be achieved, but Carbolite can make no specific warranty as to the extent to which this is possible.

1.2 Voltage and Power Control

All models in this range, from March 2001, are supplied with heating elements designed for use over the voltage range 200V-240V or 3-phase equivalents. The Carbolite control system incorporates a “power limit” which effectively limits the voltage to 208V. It is most important that any alternative system provided by the customer should be able to limit the power accordingly. See sections 3.7 and 8.2.

1.3 Switches and Lights



Supply Light: when the furnace is connected to the electrical supply the light in the adjacent switch glows



Heat Switch: the switch disconnects power to the heating elements; unless this switch is off there is a danger of electric shock when inserting objects into the furnace



Heat Light: the adjacent light glows or flashes to indicate that power is being supplied to the elements

1.4 Warning Symbols



DANGER of electrical shock—read any warning printed by this symbol.



DANGER – read any warning printed by this symbol.



DANGER – hot surface. Read any warning printed by this symbol.

WARNING: all surfaces of a furnace may be hot.

2.0 INSTALLATION

2.1 Unpacking & Handling

When unpacking or moving the furnace always lift it by its case or main body. Never lift it by its insulation or by a fitted work tube. If possible use two people to carry the furnace and remote control box. Remove any packing material from inside the furnace before use.

If an optional or special stand is separately supplied, assemble the furnace on to it. These models may be supplied for customer mounting and may require customer preparation of mounting components before installation.

2.2 Siting

Place the furnace in a well ventilated room, away from other sources of heat, and on a surface which is resistant to accidental spillage of hot materials. Do not mount the furnace on an inflammable surface.

Ensure that there is free space around the furnace. Do not obstruct any of the vents in the control box: they are needed to keep the controls cool.

Ensure that the control box is placed in such a way that it can be quickly switched off or disconnected from the electrical supply - see below.

2.3 Setting Up


If the furnace is supplied with a work tube or any accessories fit these into position.

For optimum temperature uniformity, insulating plugs should be placed in the tube ends as shown in fig.1. With a long inner work tube, the stem of the plug assembly should line up with the end of the tube as in fig.2. Alignment of radiation shields is similar to that of plugs. With these models, split end plugs are supplied; unless ordered for a specific tube size, these require shaping to fit the tube or work piece: use a round file.

If stainless steel seals with gas inlets are supplied they are to be fitted as shown in fig.3; the stem of any insulating plug should touch the seal. *Stainless steel seals for vertical use:* a hook and eye arrangement holds the upper insulating plug assembly; alternatively a gland nut.

Horizontal models: if heavy fittings are to be clamped to the end of an extended work tube they can increase the bending stress at the centre of the tube. Support such fittings in such a way that expansion of the tube is allowed.

If a metal work tube is being used in the furnace, ensure that it is earthed for operator safety.



2.4

Electrical Connections

Connection by a qualified electrician is recommended.

The furnaces covered by this manual may be ordered for single phase A.C. supply, which may be Live to Neutral non-reversible, Live to Neutral reversible or Live to Live. Some models can be supplied for three phase use (and if so, are “universal” – see section 2.5).

Check the furnace rating label before connection. The supply voltage should agree with the voltage on the label, and the supply capacity should be sufficient for the amperage on the label.



If the actual supply is not the same as the voltage on the label, then the controller power limit may need to be adjusted: set the Heater Switch to *off*, connect the furnace and see section 3.7.

The supply should be fused at the next size equal to or higher than the amperage on the label. A table of the most common fuse ratings is also given in section 8.1 of this manual. Where a supply cable is present there are internal supply fuses; customer fusing is preferred but not essential.

Furnace with supply cable: either wire directly to an isolator or fit with a line plug.

Furnace without supply cable: a permanent connection to a fused and isolated supply should be made to the internal terminals after temporary removal of the furnace back panel.

Connection by line plug: the plug should be within reach of the operator, and should be quickly removable.

Connection to isolating switch: this should operate on both conductors (single phase) or on all live conductors (three phase), and should be within reach of the operator.

The supply **MUST** incorporate an earth (ground).

CONNECTION DETAILS			<i>supply type</i>	
Supply	Terminal label	Cable colour	<i>Live-Neutral</i>	<i>Reversible or Live-Live</i>
1-phase	L	Brown	To live	to either power conductor
	N	Blue	To neutral	to the other power conductor
	PE	Green/Yellow	To earth (ground)	to earth (ground)
supply	Terminal label	Cable colour		
2- or 3-phase	L1	Black	to phase 1	
	L2	Black	to phase 2	
	L3	Black	to phase 3 <i>except 2-phase</i>	
	N	Light Blue	to neutral <i>except delta</i>	
	PE	Green/Yellow	to earth (ground)	

Do not connect a furnace ordered for three phase use to a single phase supply or to the wrong type of three phase supply – except as indicated in sections 2.5 and 7.8.

2.5 “Universal Wiring” (*year 2000 onwards*)

When (and only when) ordered for 3-phase use these furnaces are supplied in a form in which they can be easily rewired between 1-phase and 3-phase supplies. This applies to 3-phase+N and 3-phase delta in the ranges 380/220V–415/240V and 200-240V, but does not apply to 3-phase star without neutral (e.g 380V or 440V).

To alter the configuration, remove the control box back panel and alter the connections between the supply terminal block and the EMC filters, using the appropriate diagram from section 7.8.

Models ordered for single phase only are not affected and cannot be converted to 3-phase.

If in doubt, please consult Carbolite.

3.0

OPERATION

The instructions for operating the temperature controller are given in a separate manual.

If the furnace is fitted with a time switch, see also the supplementary manual MS03.

If cascade control is fitted, see the supplementary manual MS07.

3.1 3-zone Control Methods

The models in this manual are typically designed to achieve an extended uniform temperature zone by the use of three control zones, with the control zones linked so that end zones follow the central zone in a master-slave approach; there are two ways of doing this. Alternatively, independent control zones may be ordered. There are thus three control methods (A, B & C).

A. Back-to-Back Thermocouples


This is the most commonly supplied option.

The central zone of the work tube is controlled directly by the central temperature controller. Each end zone thermocouple is wired in opposition to a central reference thermocouple, and the resulting small voltage difference when the zones are at different temperatures is used by the end zone controller. The circuit diagram in section 7.1 shows the thermocouple arrangement.

Set the "setpoint" of the end zone controllers to zero. Alternatively, a small temperature difference (offset) can be created by setting a non-zero value, but the sum of the main controller set-point and the slave controller offset **MUST NOT** exceed the furnace maximum temperature. The "measured temperature" display shows the actual offset.

Sometimes a furnace using this type of control does not cool down – this may depend on the customer work load. The end controllers strive to remain at the central temperature, and prevent cooling. Should this occur, please contact Carbolite's technical department.

2132 Slave Controller Navigation Diagram



B. Retransmission of Setpoint

In this system additional communication modules are fitted in the controllers, rather than an additional thermocouple as in A. The centre zone controller informs the end-zone controllers of the setpoint that they are to follow.

It is possible to switch off the master-slave control and allow the controllers to work independently. On the end-zone controllers, scroll down to L-r and press Up or Down to alter the value from rmt (remote) to Loc (local). There is no need to alter the centre controller.

C. Independent Control

In this case the three controllers are completely independent. Note that it is not possible to maintain very different zone temperatures because of heat transfer within the work tube.

3.2

Operating Cycle

The furnace is fitted with a combined Supply light and Instrument switch. The light is on whenever the furnace is connected to the supply. The switch cuts off power to the control circuit. There is also a Heater switch which can be used to disconnect power to the elements.

Connect the furnace to the electrical supply. The Supply light should glow.

Operate the instrument switch to activate the temperature controller; the **O** position is off, the **I** position on. The controller becomes illuminated and goes through a short test cycle.

Control methods A & B: Set the slave (end zone) controllers to the desired offset temperature, usually zero. Set the main (central) temperature controller to the desired setpoint or program. See the separate manual(s) for the controller(s).

Control method C: Set the three controllers to the desired temperatures. See the separate manual(s) for the controller(s).

Overtemperature option only. If the overtemperature controller has not yet been set as required, set it and activate it according to the instructions in the appropriate manual.

Switch on the Heater switch, located on the instrument panel. Unless a time switch is fitted and is off, the furnace starts to heat up. The Heat light(s) glow steadily at first and then flash as the furnace approaches the desired temperature or a program setpoint.


Overtemperature option only. If the overtemperature trip operates then an indicator in the overtemperature controller flashes, and the heating elements are isolated. Find and correct the cause before resetting the overtemperature controller according the instructions supplied.


To switch off power to the heating elements, use the Heater Switch. To switch the furnace off, use both the Heater switch and the Instrument switch, and isolate it from the electrical supply.

3.3 General Operating Advice

Heating element life is shortened by use at temperatures close to maximum. Do not leave the furnace at high temperature when not required. The maximum temperature is shown on the furnace rating label and on the back page of this manual.

3.4 Operator Safety

 The ceramic materials used in furnace manufacture become electrically conductive to some extent at high temperatures. In these models there are partially exposed heating coils in the chamber and there is danger of contact even with the furnace closed. **DO NOT** use any conductive tools within the work tube without isolating it. If a metal work tube is used, it must be earthed (grounded).

 Switch off the Heater switch whenever loading or unloading the furnace. The elements are isolated when the Heater switch is OFF. This switch cuts both sides of the circuit directly or via a contactor (a contactor is used in models where the rated current exceeds 16 Amps).

3.5 Tube Life

A ceramic work tube may be cracked if workpieces are inserted too quickly or at temperatures below 900°C (when the tube is more brittle). Large pieces should also be heated slowly to ensure that large temperature differences do not arise.

Poor thermal contact should be encouraged between the workpiece and the tube; crucibles or boats should be of low thermal mass and should have feet to reduce the contact with the tube (fig. 4).

Do not set too high a heating rate. Large diameter tubes are more susceptible to thermal shock than smaller. Tubes which extend beyond the heated part of the furnace are more at risk. A general rule for maximum heating rate is 400/internal diameter (°C/min); for 75mm i/d tubes this comes to 5°C per minute. The controller can be set to limit the heating rate.




Fig 4
avoidance of thermal contact

3.6 Pressure

Work tubes are not able to accept high internal pressure. When gas seals or similar fittings are in use, the gas pressure should be restricted to a maximum of 0.2 bar (3 psi). A pressure of about half of that should normally be sufficient to achieve the desired flow rate. The customer must ensure that the exhaust path from the tube is not blocked, so that excess pressure does not occur.

3.7 Power Adjustment

The furnace control system incorporates electronic power limiting. The power limit parameter OP.Hi is accessible, and can be used to adjust the furnace to the actual supply voltage.

The models covered by this manual (March 2001 onwards) are designed for use over the range of voltages 200V-250V (or, if ordered, 100V-125V), and the power limit parameter is set accordingly. These models may be relocated to a different voltage within the range: the power limit should be reset to match the voltage. See section 8.2.

To alter the power limit

Set the Heater Switch to Off to prevent heating while adjusting the power limit.

Press Page \square until oP (output list) is displayed. Press Scroll \curvearrowright until OP.Hi (Output High) is displayed. Press Down \blacktriangledown or Up \blacktriangle once to display the value of OP.Hi (it is good practice to write down the original value). To alter the parameter to the desired value use Down \blacktriangledown or Up \blacktriangle .

A power setting of zero prevents the furnace from heating: useful for demonstrating the controls without taking power.

Do not increase the power limit simply “to get more power”. The elements could burn out, or a fuse could blow.

3.8 Running at Low Temperatures

The power limit may be adjusted to a low level to achieve better control when running the furnace at a low temperature. No hard and fast rules can be given, but, as an example, to run at temperatures only up to 600°C try a power limit of 50%. Control stability may fall off again if a setting below about 40% is used.

Before changing the power limit, record its factory setting for possible future use.

4.0 MAINTENANCE

4.1 General Maintenance

No routine maintenance is required. The outer surfaces may be cleaned with a damp cloth. Do not allow water to enter the case, tube or control box. Do not clean with organic solvents.

4.2 Calibration

After prolonged use the controller and/or thermocouple could require recalibration. This would be important for processes which require accurate temperature readings or which use the furnace close to its maximum temperature. A quick check using an independent thermocouple and temperature indicator should be made from time to time to determine whether full calibration is required. These items can be supplied by Carbolite.

Depending on the controller, the controller manual may contain calibration instructions.

4.3 After Sales Service

Carbolite's service division (Thermal Engineering Services) has a team of Service Engineers capable of repair, calibration and preventive maintenance of furnace and oven products at our customers' premises throughout the world. We also sell spares by mail order. A telephone call or fax often enables a fault to be diagnosed and the necessary spare part despatched.

Each furnace has its own record card at Carbolite. In all correspondence please quote the serial number, model type and voltage given on the rating label of the furnace. The serial number and model type are also given on the front of this booklet when supplied with a furnace.

To contact Thermal Engineering Services or Carbolite see the back page of this manual.

4.4 **Recommended Spares Kits**


Carbolite can supply individual spares, or a kit of the items most likely to be required. Ordering a kit in advance can save time in the event of a breakdown. Each kit comprises one of each type of thermocouple, one solid state relay, and two heating elements (models --/900: 2 of each type).

When ordering spares please quote the model details as requested above.

5.0 **REPAIRS & REPLACEMENTS**

5.1 **Safety Warning – Disconnection from Supply**

Always ensure that the furnace is disconnected from the supply before repair work is carried out.



5.2 **Safety Warning - Refractory Fibrous Insulation**

This furnace contains refractory fibres in its thermal insulation. These materials may be in the form of fibre blanket or felt, vacuum formed board or shapes, mineral wool slab or loose fill fibre.



Normal use of the furnace does not result in any significant level of airborne dust from these materials, but much higher levels may be encountered during maintenance or repair.

Whilst there is no evidence of any long term health hazards, we strongly recommend that safety precautions are taken whenever the materials are handled.

Exposure to dust from fibre which has been used at high temperatures may cause respiratory disease.

When handling fibre always use an approved mask, eye protection, gloves and long sleeved clothing.

Avoid breaking up waste material. Dispose of waste fibre in sealed containers.

After handling rinse exposed skin with water before washing gently with soap (not detergent). Wash work clothing separately.

Before commencing any major repairs we recommend reference to the European Ceramic Fibre Industry Association Bulletin No. 11 and the UK Health and Safety Executive Guidance Note EH46.

We can provide further information on request. Alternatively our service division can quote for any repairs to be carried out at your premises or ours.

5.3 **Temperature Controller Replacement**

201. This controller is fitted to the back of the control panel; in many models this can be separated from the base by removal of two screws.



Before handling the controller: **wear an anti-static wrist strap** or otherwise avoid any possibility of damage to the unit by static electricity.

Refer to the detailed instructions supplied with the replacement controller.

2132, 2416, 2408 etc. Ease apart the two lugs at the side; grip the instrument and withdraw it from its sleeve; push in the replacement.

5.4

Solid-state Relay Replacement

Disconnect the furnace from the supply and remove the back panel from the base or control box..

Make a note of how the wires are connected to the solid state relay, and disconnect them.

Remove the solid state relay from the base panel or aluminium plate.

Replace and reconnect the solid state relay ensuring that the heat-conducting thermal pad is sandwiched between the relay and the base panel or aluminium plate. Alternatively a thin layer of white, heat-conducting silicon paste may be applied between the new relay and the plate.

The new solid state relay contains a built-in MOV which protects it from short periods of excess voltage. A separate MOV is not required.

Replace the removed panel.

5.5 Thermocouple Replacement

The coverings and guards which must be removed to gain access to the thermocouples depend on the model, and any mounting options or fittings. Study the furnace layout and consult Carbolite if in doubt.

Disconnect the furnace from the supply, and remove covers and guards as necessary.

Make a note of the thermocouple connections. The negative leg of the thermocouple is marked blue. Compensating cable colour codings are:

negative: white positive (type N): pink

Disconnect the thermocouple from its terminal block.

Withdraw the thermocouple from its sheath (the narrow-bore built-in tube) and remove any broken bits of thermocouple.

Bend the new thermocouple carefully to match the shape of the original (working from the terminal end). Should the overall length differ from that of the original provided, ensure that the tip ends up the same distance from the end as it did in the original.

Insert the new thermocouple into position, restoring any removed porcelain spacers, and ensuring correct polarity.

Re-assemble the furnace.

5.6 Fuse Replacement

Fuses are marked on the circuit diagram (section 7.1) with type codes, e.g. F1, F2. A list of the correct fuses is given in section 8.1. *Depending on model and voltage, the different fuse types may or may not be fitted.*

If any fuse has failed, it is advisable for an electrician to check the internal circuits.

Replace any failed fuses with the correct type. For safety reasons do not fit larger capacity fuses without first consulting Carbolite.

The fuses are near the cable entry point, and access is by removal of the back panel of the control box.

5.7

Element Replacement



Please see safety note 5.2 - please wear a face mask.

HZS and TVS with far hinge: Remove the three screws from each end and lift out the half-circular insulation assembly.

Make a plan of all the cable connections and disconnect the cables.

Remove the thermocouples by withdrawing them from the sheaths built into the elements. Remove the plates through which the element tails are located. Remove the keep plates from each side of the insulation assembly.

Lift out the element to be replaced; save any insulation sleeves for possible reuse.

Bend or cut the new element tails as necessary, and fit any insulation sleeves; feed the tails through and fit the element into place.

Refit the keep plates on each side. Refit the tail termination plates, ensuring that the element tails do not touch any metal parts. Refit the thermocouples.

Connect all the wiring according to the plan previously made, and complete the reassembly of the furnace.

Check that the furnace is controlling properly to rule out the possibility that the element failed because of a fault in the control system.

HZS & TVS Elements				
each element is a half-cylinder				
<i>in this table the suffix E refers to a furnace ordered with equal zone lengths</i>				
HZS & TVS 12/--/600	200-240V	4 pairs in parallel, each pair 2 in series	100-120V	8 elements in parallel
HZS & TVS 12/--/600E (equal zones)	200-240V	3 pairs in parallel, each pair 2 in series	100-120V	6 elements in parallel
HZS & TVS 12/--/900	200-240V	5 pairs in parallel, each pair 2 in series	100-120V	10 elements in parallel
HZS & TVS 12/--/900E (equal zones)	200-240V	6 pairs in parallel, each pair 2 in series	100-120V	12 elements in parallel
12/--/600 has 4 pairs of 150mm length 12/--/600E has 3 pairs of 200mm length 12/--/900 has 2 pairs of 150mm length (ends) and 3 pairs of 200mm length (centre) 12/--/900E has 6 pairs of 150mm elements				

Wherever two different sizes of elements are fitted, the 150mm elements are at the ends and the 200mm elements in the centre.

6.0

FAULT ANALYSIS

A. Furnace Does Not Heat Up

- | | | | |
|----|-------------------------------------|--|--|
| 1. | The HEAT light is ON | → The heating element has failed | → Check also that the SSR is working correctly |
| 2. | The HEAT light is OFF | The controller shows a very high temperature or a code such as S.br | → The thermocouple has broken or has a wiring fault |
| | | The controller shows a low temperature | → The door switch(es) (if fitted) may be faulty or need adjustment |
| | | | → The contactor (if fitted) may be faulty |
| | | | → The SSR could be failing to switch on due to internal failure, faulty logic wiring from the controller, or faulty controller |
| | | There are no lights glowing on the controller | → The SUPPLY light is ON → The controller may be faulty or not receiving a supply due to a faulty switch or a wiring fault |
| | | | → The SUPPLY light is OFF → Check the supply fuses and any fuses in the furnace control compartment |

B. Furnace Overheats

- | | | | |
|----|---|---|--|
| 1. | The HEAT light goes OFF with the instrument switch | → The controller shows a very high temperature | → The controller is faulty |
| | | → The controller shows a low temperature | → The thermocouple may have been shorted out or may have been moved out of the heating chamber |
| | | | → The thermocouple may be mounted the wrong way round |
| | | | → The controller may be faulty |
| 2. | The HEAT light does not go off with the instrument switch | → The SSR has failed "ON" | → Check for an accidental wiring fault which could have overloaded the SSR |


7.0

CIRCUIT DETAILS

Safety Switches type A: a 2-pole Heater Switch is fitted directly in the element circuit in models up to 16A rating. Two “door switches” are also fitted in the element circuit up to 25A rating.

Safety Switch type B: a Heater Switch is fitted into the contactor coil circuit in models over 16A. A door switch is fitted into the contactor coil circuit over 25A rating.

7.1 Single Phase (example for control method A)



7.2 2- or 3-Phase with neutral

Each SSR is connected to a different phase. The control circuit is taken between L1 and N.

Safety switch A applies for 2-phase. Safety switch B applies for 3-phase.


If type F1 fuse is present, one per phase if fitted. If type F2 fuse is present, one is fitted; if type F3 fuse is present, one per phase is fitted.

Note that on 2- or 3-phase models there may be three separate neutrals taken to a common supply terminal, depending on EMC filter requirements.

7.3 Independent Zones (control method C)

When this is ordered there are three independent thermocouples (instead of the four shown) connected to the three controllers; the words “master” and “slave” may be replaced by “centre” and “end”.

7.4 Three-phase without neutral (delta, e.g. 208-240V)



7.5 Three phase without neutral (star – e.g. 380-415V)

The circuit is similar to 7.4, but the “neutral” ends of the elements are not connected to a neutral terminal block.

The control circuit contains an isolating transformer to reduce the control voltage to 240V or similar.


7.6 Higher Voltages (e.g. 254V)

For 254V or above, an isolating transformer is included in the control circuit.


7.7 Model Configurations

These models normally have end zones of pair of elements each; the centre zone comprises the remaining elements wired in parallel. By special order the zones can be of other lengths.

There are many possible electrical configurations for these models covering 1- 2- or 3-phase, including 3-phase delta. Further information on the circuit diagram for a specific configuration can be obtained from Carbolite (please state the furnace serial number).




7.8 3-phase “universal” wiring




Fuses F1 are always present in this wiring design.
 Fuses F2 could be absent in some circumstances, if the circuit does not exceed 10A.
 Fuses F3 are present if the circuit exceeds 25A, but otherwise are usually absent.


3-phase + neutral



3-phase delta



1-phase



A model made to this diagram can be converted by the customer between the following supply voltages:

- between 3-phase + neutral in the range 380/220V – 415/240V
- and 3-phase delta in the range 200V – 240V
- and single phase in the range 200V – 240V

8.0

FUSES & POWER SETTINGS

8.1 Fuses

F1	Internal supply fuses	Fitted if supply cable fitted. Fitted on board to some types of EMC filter.	on-board and up to 16 Amps: 32mm x 6mm type F other: GEC Safeclip
F2	Auxiliary circuit fuses	Fitted on board to some types of EMC filter. May be omitted up to 25Amp/phase supply rating.	2 Amps glass type F On board: 20mm x 5mm Other: 32mm x 6mm
F3	Heat Light fuses	May be omitted up to 25 Amp/phase supply rating.	2 Amps glass type F 32mm x 6mm
	Customer fuses	Required if no supply cable fitted. Recommended if cable fitted.	See rating label for amperage; see table below for fuse rating.

Access to internal fuses is by removal of the back panel of the control box.

Model (from March 2001)	phases	Volts	Supply Fuse Rating
HVS & TVS 12/--/600	1-phase	200-240	15-16A **
HVS & TVS 12/--/600	3-phase + N	380/220-415/240	10A
HVS & TVS 12/--/600	3-phase delta	200-240	10A
HVS & TVS 12/--/600E	1-phase	200-240	15-16A **
HVS & TVS 12/--/600E	3-phase + N	380/220-415/240	5A
HVS & TVS 12/--/600E	3-phase delta	200-240	10A
HVS & TVS 12/--/900	1-phase	200-240	25A
HVS & TVS 12/--/900	3-phase + N	380/220-415/240	10A
HVS & TVS 12/--/900	3-phase delta	200-240	15A
HVS & TVS 12/--/900E	1-phase	200-240	25A
HVS & TVS 12/--/900E	3-phase + N	380/220-415/240	10A
HVS & TVS 12/--/900E	3-phase delta	200-240	12.5A

*Other models or voltages: check the rating label for details of the supply.
Before March 2001 – please check with Carbolite if in doubt*

8.2 Power Settings

The standard power limit settings (parameter OP.Hi) are as follows:

Volts:	100V	110V	120V	127V
	200V	220V	240V	254V
<i>HVS or TVS 12/--</i>	208V	380V	415V	440V
before March 2001 – all models	100	100	100	89
from March 2001 **	100	89	82	75
			75	67

See section 3.7 for further detail.

** if you have specially ordered model --/600 for use in UK on a 13A supply, then the power limit is 100% and the amps rating is 12.5A; please check your rating label.

9.0

SPECIFICATIONS

Carbolite reserves the right to change specifications without notice.

9.1 Models Covered by this Manual

MODEL	Max. Temp. (°C)	Max. Power (kW)	Work Tube Bore (mm)	Work Tube Length (mm)	Heated Length (mm)	Uniform Zone Length ¹ (mm)	Net Weight ² (kg)
<i>3-zone Split Tube furnaces heated by resistance wire moulded in refractory fibre</i>							
<i>Horizontal Models in an opening case</i>							
HZS 12/--/600	1200°C	3.0	25-100	700-	600		41
HZS 12/--/900	1200°C	4.5	20-100	1000-	900		60
<i>Vertical Models with a variety of stand and fixing options</i>							
TVS 12/--/600	1200°C	3.0	25-100	700-	600		35
TVS 12/--/900	1200°C	4.5	20-100	1000-	900		50
<i>Models above have end zones of 150mm unless specially ordered. Models with suffix E have equal zones (3 x 200mm or 3 x 300mm)</i>							
<i>Also models based on the above, but of other lengths, supplied to special order.</i>							

note 1: The figures for uniform zone length are for $\pm 5^{\circ}\text{C}$ and are based on measurements with the furnace horizontal and fitted with insulating plugs in both tube ends. They assume the use of master-slave control.

note 2: Weights are approximate for horizontal models and do not include fittings or vertical stands.

9.2 Environment

The furnaces contain electrical parts and should be stored and used in indoor conditions as follows:

temperature: $5^{\circ}\text{C} - 40^{\circ}\text{C}$

relative humidity: maximum 80% up to 31°C decreasing linearly to 50% at 40°C