

# VELOCICALC® Air Velocity Meter

Model 9525

Operation and Service Manual



TRUST. SCIENCE. INNOVATION.

## Copyright©

TSI Incorporated / May 2007 / All rights reserved.

### **LIMITATION OF WARRANTY AND LIABILITY (effective July 2000)**

Seller warrants the goods sold hereunder, under normal use and service as described in the operator's manual, shall be free from defects in workmanship and material for twenty-four (24) months, or the length of time specified in the operator's manual, from the date of shipment to the customer. This warranty period is inclusive of any statutory warranty. This limited warranty is subject to the following exclusions:

- a. Hot-wire or hot-film sensors used with research anemometers, and certain other components when indicated in specifications, are warranted for 90 days from the date of shipment.
- b. Parts repaired or replaced as a result of repair services are warranted to be free from defects in workmanship and material, under normal use, for 90 days from the date of shipment.
- c. Seller does not provide any warranty on finished goods manufactured by others or on any fuses, batteries or other consumable materials. Only the original manufacturer's warranty applies.
- d. Unless specifically authorized in a separate writing by Seller, Seller makes no warranty with respect to, and shall have no liability in connection with, goods which are incorporated into other products or equipment, or which are modified by any person other than Seller.

The foregoing is IN LIEU OF all other warranties and is subject to the LIMITATIONS stated herein. **NO OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR PARTICULAR PURPOSE OR MERCHANTABILITY IS MADE.**

TO THE EXTENT PERMITTED BY LAW, THE EXCLUSIVE REMEDY OF THE USER OR BUYER, AND THE LIMIT OF SELLER'S LIABILITY FOR ANY AND ALL LOSSES, INJURIES, OR DAMAGES CONCERNING THE GOODS (INCLUDING CLAIMS BASED ON CONTRACT, NEGLIGENCE, TORT, STRICT LIABILITY OR OTHERWISE) SHALL BE THE RETURN OF GOODS TO SELLER AND THE REFUND OF THE PURCHASE PRICE, OR, AT THE OPTION OF SELLER, THE REPAIR OR REPLACEMENT OF THE GOODS. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES. SELLER SHALL NOT BE RESPONSIBLE FOR INSTALLATION, DISMANTLING OR REINSTALLATION COSTS OR CHARGES. No Action, regardless of form, may be brought against Seller more than 12 months after a cause of action has accrued. The goods returned under warranty to Seller's factory shall be at Buyer's risk of loss, and will be returned, if at all, at Seller's risk of loss.

Buyer and all users are deemed to have accepted this LIMITATION OF WARRANTY AND LIABILITY, which contains the complete and exclusive limited warranty of Seller. This LIMITATION OF WARRANTY AND LIABILITY may not be amended, modified or its terms waived, except by writing signed by an Officer of Seller.

### **Service Policy**

Knowing that inoperative or defective instruments are as detrimental to TSI as they are to our customers, our service policy is designed to give prompt attention to any problems. If any malfunction is discovered, please contact your nearest sales office or representative@0

# CONTENTS

<b>CHAPTER 1 UNPACKING AND PARTS IDENTIFICATION .....</b>	<b>1</b>
<b>CHAPTER 2 SETTING-UP .....</b>	<b>3</b>
Supplying Power to the Model 9525 .....	3
Installing the Batteries .....	3
Using the Telescoping Probe .....	3
Extending the Probe .....	3
Retracting the Probe.....	3
<b>CHAPTER 3 OPERATION .....</b>	<b>5</b>
Keypad Functions .....	5
<b>CHAPTER 4 MAINTENANCE .....</b>	<b>7</b>
Recalibration .....	7
Cases .....	7
Storage .....	7
<b>CHAPTER 5 TROUBLESHOOTING.....</b>	<b>9</b>
<b>APPENDIX A SPECIFICATIONS.....</b>	<b>11</b>





# Chapter 1

## **Unpacking and Parts Identification**

---

Carefully unpack the instrument and accessories from the shipping container. Check the individual parts against the list of components below. If anything is missing or damaged, notify TSI immediately.

1. Carrying case
2. Instrument



## Chapter 2

### Setting-up

---

#### Supplying Power to the Model 9525 VELOCICALC Air Velocity Meter

The Model 9525 is powered with four size AA batteries.

##### Installing the Batteries

Install batteries by loosening the screw in the battery access cover located on the back of the instrument. Insert four AA-size alkaline batteries in the battery tubes according to the polarity indicated on the instrument case under the battery access cover. Replace the battery access cover and tighten the screw.

<b>WARNING:</b>
-----------------

The Model 9525 is only listed for intrinsic safety when operating with four size AA alkaline batteries. Batteries of other types (NiCd, carbon-zinc, etc.) are <b>not</b> acceptable for use in a hazardous environment.
--

##### Using the Telescoping Probe

The telescoping probe contains the velocity sensor. When using the probe, make sure the sensor window is fully exposed and the orientation dimple is facing upstream.

##### Extending the Probe

To extend the probe, pull the black tip of the probe from the center of the instrument. Once extended to its three-inch length, the probe can rotate 90° to measure air from many directions.

##### Retracting the Probe

To retract the probe, align the sensor window so that you can view straight through the window from the front of the instrument. Once the window is aligned to the front, grasp the probe tip and push firmly straight into the instrument case. Always store the probe retracted when not in use in order to protect the sensor.



# Chapter 3

## Operation

---

### Keypad Functions

<b>ON/OFF Switch</b>	The ON/OFF switch is used to turn on or turn off power to the Model 9525. When the Model 9525 is turned on, it will display approximate battery life in percent for five seconds.
<b>BATT/VEL Switch</b>	This switch is used to change the display to read air velocity or approximate percentage of remaining battery life.
<b>FAST/SLOW Switch</b>	This switch is used to change the display average of the Model 9525. When set to FAST, the display average is approximately 3 seconds. When set to SLOW, the display average is approximately 12 seconds.



## Chapter 4

### **Maintenance**

---

The Model 9525 requires very little maintenance to keep it performing well.

#### **Recalibration**

To maintain a high degree of accuracy in your measurements, we recommend that you return your Model 9525 to TSI for annual recalibration. Please contact one of TSI's offices or your local distributor to make service arrangements and to receive a Return Material Authorization (RMA) number.

---

#### **Cases**

If the instrument case or storage case needs cleaning, wipe it off with a soft cloth and isopropyl alcohol or a mild detergent. Never immerse the Model 9525. If the enclosure of the Model 9525 becomes broken, it must be replaced immediately to prevent access to hazardous voltage.

#### **Storage**

Remove the batteries when storing the unit for more than one month to prevent damage due to battery leakage.



# Chapter 5

## Troubleshooting

Table 5-1 lists the symptoms, possible causes, and recommended solutions for common problems encountered with the Model 9525. If your symptom is not listed, or if none of the solutions solves your problem, please contact TSI.

**Table 5-1: Troubleshooting the Model 9525**

Symptom	Possible Causes	Corrective Action
No display.	Unit not switched on	Switch unit on
	Low or dead batteries	Replace batteries
	Dirty battery contacts	Clean battery contacts
	Batteries installed incorrectly	Check battery alignment against illustration inside battery cover
BAT is blinking	Batteries are getting low	Replace batteries
Display reads “LO” and the BAT indicator is on	Batteries are low	Replace the batteries
	Dirty battery contacts	Clean the battery contacts
Velocity reading fluctuates badly	The flow is fluctuating	Reposition the probe in a less turbulent section of the flow or set the RESPONSE switch to SLOW
Velocity reading blinks 2000 FPM or 10.16 m/s	The velocity exceeds 2000 FPM or 10.16 m/s	Use an alternative method to measure the velocity
	Sensor may be damaged	Contact TSI
Display indicates greater than 10 FPM (0.05 m/s) in zero flow condition	Sensor may be damaged	Contact TSI

### WARNING!

Remove the probe from excessive temperature immediately: excessive heat can damage the sensor. Operating temperature limits can be found in [Appendix A, Specifications](#).



# Appendix A

## Specifications

---

Specifications are subject to change without notice.

### Velocity:

Range: 0 to 2000 ft/min (0 to 10 m/s)

Accuracy<sup>1&2</sup>:  $\pm 5\%$  of reading or  $\pm 5$  ft/min ( $\pm 0.05$  m/s), whichever is greater

Resolution: 1 ft/min (0.01 m/s)

### Instrument Temperature Range:

Operating (Electronics): 40 to 113°F (5 to 45°C)

Operating (Probe): 32 to 122°F (0 to 50°C)

### External Meter Dimensions:

Instrument: 2.7 in.  $\times$  5.2 in.  $\times$  1.3 in. (6.8 cm  $\times$  13.2 cm  $\times$  3.3 cm)

Probe: 0.25 in diameter (6.4 mm)

3.1 in. length (7.9 cm)

### Meter Weight:

Weight with batteries: 0.6 lbs (0.27 kg)

### Meter Display Dimensions:

4-digit LCD, 0.4 in. (10 mm) digit height

### Power Requirements:

Four AA-size batteries (included)

### Safety Rating:

UL Listed

Intrinsically safe for use in hazardous locations for Class I Groups C and D, Class II Groups E, F, and G, and Class III, only when used with four size AA alkaline batteries.

<sup>1</sup> Temperature compensated over an air temperature range of 40 to 150°F (5 to 65°C).

<sup>2</sup> The accuracy statement of  $\pm 5.0\%$  of reading or  $\pm 5$  ft/min ( $\pm 0.05$  m/s), whichever is greater, begins at 30 ft/min through 2000 ft/min (0.15 m/s through 10.16 m/s).





Thank you for reading this data sheet.

For pricing or for further information, please contact us at our UK Office, using the details below.



**UK Office**

**Keison Products,**

**P.O. Box 2124, Chelmsford, Essex, CM1 3UP, England.**

**Tel: +44 (0)1245 600560**

**Fax: +44 (0)1245 600030**

**Email: [sales@keison.co.uk](mailto:sales@keison.co.uk)**

Please note - Product designs and specifications are subject to change without notice. The user is responsible for determining the suitability of this product.