

*Installation,
Operation and
maintenance Guide*

**CPS_CPS 10
System**



Part Number: NPCPSGB
Revision: J.1

OLDHAM
The Fixed Gas Detection Experts

Copyright 2017 by OLDHAM

February 2017

All rights reserved. Reproduction in any form, in whole or in part, without the express written consent of OLDHAM is strictly prohibited.

The information contained within this manual is true and correct to the best of our knowledge.

Due to ongoing research and development, the specifications of this product may be changed at any time without notice.

GAS DETECTION

We are delighted that you have chosen an **OLDHAM** instrument and would like to thank you for your choice.

We have taken all the necessary measures to ensure that your instrument provides total satisfaction.

Now it is important to read this document carefully.

EXTENT OF RESPONSIBILITY

- * **OLDHAM** declines its responsibility towards any person for material damage, physical injury or death resulting wholly or partly from inappropriate use, installation or storage of its equipment resulting from failure to observe instructions and warnings and/or standards and regulations in force.
- * **OLDHAM** neither supports nor authorises any company, physical or moral person to assume responsibility on behalf of **OLDHAM**, even if it is involved in the sale of **OLDHAM** products.
- * **OLDHAM** cannot be held responsible for direct or indirect damage or be required to pay direct or indirect compensation resulting from the sale or use of any of its products **IF THESE PRODUCTS HAVE NOT BEEN DEFINED AND CHOSEN BY OLDHAM FOR THEIR SPECIFIC USE.**

CLAUSES CONCERNING PROPERTY

- * Drawings, plans, specifications and information included in this document contain confidential information that is the property of **OLDHAM**
- * None of this information may be reproduced, copied, divulged or translated, by physical, electronic or any other means, nor used as the basis for the manufacture or sale of **OLDHAM** equipment or for any other reasons **without prior consent from OLDHAM**

WARNINGS

- * This document is not contractually binding. In the interests of its customers, **OLDHAM** reserves to modify the technical specifications of its equipment without notice, in order to improve its performance.
- * **READ THIS MANUAL CAREFULLY BEFORE FIRST USE OF THE EQUIPMENT:** this manual must be read by any person who is or will be responsible for using, maintaining or repairing this equipment.
- * **This equipment will only provide the announced performance levels if it is used, maintained and repaired according to OLDHAM directives, by OLDHAM personnel or by personnel approved by OLDHAM**
- * **The CPS model is not intended to be used as Life Safety Equipment**

GUARANTEE

2 years guarantee in normal conditions of use on parts and technical labour, return in our workshops, excluding consumables (sensors, filters, etc.)

General Information

Please read the following notice carefully before installation and start-up, paying particular attention to the end-user material safety instructions. This user's guide should be distributed to every individual involved in the installation, operation, maintenance or repair of the CPS system.

The information contained in this manual, the data and technical drawings are correct as of the date of publication. Should questions arise, please contact OLDHAM for additional information.

This manual is designed to provide users with simple and precise information. OLDHAM shall not be responsible or liable for any misinterpretation that may result from the reading of this manual. Although every effort is made to ensure accuracy, this manual may contain unintentional technical inaccuracies.

OLDHAM reserves the right to modify the technical characteristics of its equipment without notice to improve product performance on behalf of its clients.

This manual is a translation of the French original. In case of discrepancy between the French version and any translated version, the French version shall take precedence and shall prevail in all matters pertaining to any relationship between the parties.

i This icon indicates that there is additional useful information for a particular topic.

Safety Warnings

Pictogram labels have been placed on the central controller to call attention to general use safety precautions. These labels are an integral component of the central controller. Replace any label that has peeled off or become illegible. The meanings of these labels are explained below.



Ground terminal



Safety ground terminal



Risk of electric shock



Caution (see accompanying documentation)



European Union (and EEA) only. This icon indicates that in accordance with Directive DEEE (2002/96/CE) and with the regulations specific to your country, this product may not be disposed of with household waste.

Dispose of this product at a collection site intended for electrical waste, for example an official EEE (electrical and electronic equipment) collection site with a recycling or take-back program for authorized products which are available to consumers whose purchases are intended to replace old EEE products with new equivalents.

Failure to comply with regulations for the disposal of this type of waste can be harmful to the environment and to public health, as EEE products typically contain substances that may be dangerous. Your complete cooperation with the disposal of this product will help to ensure a more efficient use of natural resources.

Important Information

The modification of any piece of equipment or the use of any third party parts will automatically void all guarantees.

The central controller is intended to be used for precise applications of a technical nature. Exceeding the indicated values is strictly prohibited.


 WARNING	
The installation of this product and all electrical connections should be performed by a qualified professional, in accordance with the manufacturer's specifications and with the standards of authorities in the field.	
Failure to observe these warnings may result in serious injury. Exercise great caution, particularly when working with electricity during installation (couplings, network connections).	

Table of Contents

Chapter 1	Overview of the CPS System.....	7
	The CPS central controller.....	9
	Digital addressable modules.....	9
	Digital linking.....	10
	The COM_CPS software application	11
	System Architecture.....	12
Chapter 2	Assembly / Installation.....	13
	Installation of the CPS central controller.....	13
	Mounting the metal wall casing.....	13
	Mounting the 19" 4U rack	13
	Installing digital modules.....	14
	Mounting the CPS 10 sensor module	14
	Mounting the other modules	14
	Connection of modules in a line.....	14
Chapter 3	The CPS Central Measuring Controller.....	15
	View of rack-mounted CPS	15
	View of wall-mounted CPS	15
	Central controller electrical connections	16
	Main power supply.....	16
	Grounding the central controller.....	16
	Digital lines	16
	Internal relay dry contacts.....	16
	RS-485 serial link out.....	16
	Overview of the Motherboard.....	18
	Inspecting the digital buses.....	19
	Mini-switches	19
	Internal relay and buzzer	19
	USB / RS-232 serial connectors	20
	RS-485 serial connection (3)	20
	Printer (Optional feature)	21
	The front panel circuit	22
	Display Screen.....	22
	Keys.....	22
	Lights	22
	Alarm thresholds	23
	Alarm acknowledgement.....	23
Chapter 4	Digital Modules.....	25
	View of Digital Modules.....	25
	Connecting Digital Modules.....	26
	General topology of the RS-485 network	26
	Wiring the digital network.....	26
	Configuring the communication settings	27
	Slave address	27
	End of line resistor	27
	CPS 10 Detector Module	28
	Available Detector Types	28
	Detector settings.....	28
	External relay module	29
	Relay status lights.....	29
	“Positive/negative” relay security	29
	Relay configuration	30
	Logic Input Module	32
	Analog Outputs Module	32

Chapter 5	Detailed Menus.....	35
Menu Tree.....		35
Start-up Phase		36
Control Menu.....		37
Normal Display		37
Sensor Display.....		37
Events.....		38
Relay Status		38
4-20 mA Output Status		38
Printing.....		39
Acces code.....		39
System Menu.....		40
Line, Module, Relay Action		40
Date and Time		41
Start-up Configuration.....		41
Maintenance Menu.....		42
Simulation		42
Module Verification		43
Bus Faults.....		45
Reset maintenance.....		45
Chapter 6	Maintenance	47
Program transfer.....		47
PC → CPS transfer.....		47
CPS → PC transfer.....		47
Error messages.....		48
Checksum error		48
Testing and calibration of stable installations		49
Sensor replacement.....		49
Semi-automatic calibration.....		50
Manual calibration.....		51
Semi-automatic calibration device		52
Central controller maintenance		53
Lithium battery		53
Back-up battery pack		53
Scrapping of CPS System.....		53
Chapter 7	Technical Specifications.....	55
CPS Central Controller		55
CPS 10 Sensor Module.....		56
CPS RM4 or RM8 Relay Module.....		56
CPS DI16 Logic Inputs Module		56
CPS AO4 Analog Output Module.....		56
Chapter 8	Annexes	57

The system consists of:


- a central controller for collecting readings and managing alarms;
- various addressable digital modules (sensor modules, relay modules, analog output modules, logic input modules);
- instruments and accessories to process alarms and actions

The CPS system can manage the detection of **10 different gases**, and all detectors are clearly localized and identified.

Data from each sensor is collected in the central controller in less than one second. If gas levels exceed the programmed limits, an audiovisual alarm is triggered and can activate the ventilation system in the affected area of the parking facility.


Use the **COM_CPS software** to program the central controller.

The system status can be quickly verified with semi-automatic calibration for various sensors.




The CPS central controller

CPS : Wall mounted version



CPS : Rack mounted 19" 4U



The central controller is available in a 19" 4U (rack-mount) version or in a wall-mount version. It is designed to control:

- **256 digital modules distributed over 8 lines, with a maximum of 32 modules per line;**
- **256 addressable relays** max. distributed across all relay modules;
- **224 logic inputs** max. distributed across all logic input modules and relay modules.
- **256 analog outputs** max. distributed across 4 analog outputs modules.

Modules are connected through a digital RS-485 network using JBUS/MODBUS protocol.

The central controller connects to 256 toxic sensors, and **runs on only 24 Watts**.






The central controller can be connected to a supervision system via an RS-485 output interface using ModBus protocol.

Optional features include:

- **a battery back-up**, ensuring continual operation in case of a power outage (approx. 1 hour for 50 TOX-type sensors);
- **an integrated printer** (rack-mounted version only) for recording alarms and events;
- **an external printer** (for both rack- and wall-mounted versions).

Digital addressable modules


Various digital addressable modules can be positioned on the same line.

	CPS 10	SENSOR MODULE CO, NO, NO2, CH4, LPG, ...
	CPS RM4	RELAY MODULE 4 relays + 2 LI* 8 relays + 2 LI* (*): LI = Logic Input
	CPS RM8	
	CPS AI16	LOGIC INPUT MODULE 16 Logic Inputs
	CPS AO4	ANALOG OUTPUT MODULE 4 opto-isolated 4-20 mA outputs + 2 LI*

Digital linking

Modules are linked in-line via an MPI 22 or equivalent RS-485 double twisted pair cable, at least 0.22 mm² in diameter. One pair supplies power to the module, the second pair is used for the digital RS-485 link.

ISC – personnel should verify that the correct cable has been used in terms of type and capacity.



The **COM_CPS** software application

The **COM_CPS** software application is designed to help configure the CPS central measuring controller on a PC. **COM_CPS** software operations are addressed in a separate manual.

System and Hardware Requirements:

COM_CPS must be installed on a PC running Windows 2000 or Windows XP.

The minimum requirements to install **COM_CPS** are:

- Windows 98 SE, Windows NT, Windows 2000, Windows XP with 256 MB RAM, Windows VISTA.
- A CD-ROM drive
- At least 10 MB of free hard drive space
- A USB connection (cable not included) or a free RS-232 port (specific cable provided) to link the CPS central measuring controller to the PC.

Refer to the **COM_CPS software instructions before installing or using the software, and before programming the central controller.**

The **COM_CPS** software allows you to:

- configure one or more central controller(s) via PC;
- save settings and upload them later to the CPS central controller(s).
- view or modify central controller configuration data within the application.


The **COM_CPS** software can be used to modify the following main configuration settings:

- STEL and TWA calculations
- Predefined status tables printing times
- Conditions that would activate an internal buzzer
- Communication speed for the RS-485 series connection with a master device
- Settings for various sensors and alarm values
- Personalized sensor add-on options
- Delay settings
- Rising edge or falling edge triggers
- Average alarm integration time
- Verification of explosive gasses
- Creation of installation architecture: sensors/relays

COM_CPS

Whenever this sign appears in front of a chapter, the functions described in that chapter are configured with the **COM_CPS** software.

System Architecture




Installation of the CPS central controller

The CPS central controller should be installed in a dry, climate-controlled area protected from explosive gases and dust. Ideally, the station should be located in a secure, accessible location under surveillance (security office, control room, equipment room ...).

Mounting the metal wall casing


For the wall-mounted CPS in a metal case: *The central controller cover opens at a 90° angle to the left. Make sure to leave adequate space to completely open the cover once the central controller is mounted.*



Mounting the 19" 4U rack

The 19" 4U rack version CPS can be integrated into a rack or a 19" cabinet:

Mount the display at eye level for optimal viewing. Leave at least ½ U (22 mm) on all sides of the central controller to ensure proper ventilation.



Installing digital modules

Mounting the CPS 10 sensor module

Mount the sensor modules on a flat surface using two screws (Fig. 1).

The modules should be placed in an accessible area, so that maintenance and inspection operations can be conducted as easily and as safely as possible. Nothing in the area should prevent the sensors from obtaining measurements of the ambient environment.

When mounting the sensor module on a vertical surface, position the cable glands on the underside of the module to ensure proper calibration.

Mounting the other modules

The other modules (relay, logic input, analog output) should be mounted on a DIN rail inside of a cabinet or an electric box. (Fig. 2).

Fig.1 DETECTOR MODULE CPS 10






Fig. 2 : ADDRESSABLE DIGITAL MODULE



Connection of modules in a line



i IMPORTANT: All modules in a line should be wired in-line from the central controller, not in a hub and spoke model.



Chapter 3 The CPS Central Measuring Controller

View of rack-mounted CPS

View of wall-mounted CPS





PART	DESCRIPTION	PART NUMBER
A	CPS WALL CASING	6 514 868
B	CPS RACK 19" 4U	6 514 869
1	CPS FRONT PANEL	6 122 477
2	AP1200 PRINTER	6 114 632
3	BATTERY PACK (OPTIONAL)	6 311 098
4	CPS MOTHERBOARD	6 451 596
5	24V 60W POWER SUPPLY BOARD	6 111 308
6	CPS CENTRAL CONTROLLER DISPLAY	6 133 707
7	RS232 SUB D9 CONNECTOR	6 116 263
8	M16 GROMMET: D5 to D7mm	6 131 166
9	M20 CABLE GLANDS : D6 to D12 mm M20 PE PLASTIC SCREW	6 143 504 6 143 529

Central controller electrical connections

Electrical connections are wired through the central controller MOTHERBOARD and the power supply 24V. For the CPS central controller (wall-mounted version), you must open the casing door to access the electrical panel.

Electrical connections must be done by a qualified professional. Observe all current Directives, notably the European Low Voltage Directive. Customers in France must observe standard NF C 15-100.

 WARNING
Contact with voltage may result in serious injury or death.
Install all equipment and complete all wiring work before turning on the power.

 WARNING
Improper installation can result in incorrect gas level readings or system failure.
Carefully follow all instructions to ensure proper system operation.

Main power supply

Test the current and voltage running through a network before making any connections. Never connect the device without first disconnecting the power supply. The central controller does not have an on/off switch.

Protect the central controller from upstream current with a 4A bipolar differential circuit breaker with a type D response curve. This circuit breaker must be included in the electrical installation of the building and must be placed near of the device and must be available for the operator. On the circuit breaker will be indicated that it is the circuit breaker of the device.

Main power supply 100-240VCA: connector terminals L, N, and PE of the power supply 24V (Fig 3) for wall-mounted version or see connector picture 4 for rack version..


Pre-cabled wires are used to connect to the 24 VDC power supply module. The transformer output connector is also hardwired to link to the 24 VDC central controller connector and to the (optional) integrated printer for the rack-mounted version.

Grounding the central controller

The central controller is intended for use in areas that meet the Class II requirements for overvoltage and degree of pollution as per EN IEC 60947-1. In order to comply with the standard, the internal ground terminal *must* be grounded (Fig 3).

Digital lines

The various digital modules are connected with "Bus" connectors (Fig. 5). Recommended cable: RS-485: 2 shielded twisted pairs, 100 Ω .

One pair is used to power the module, and the other is used for communication. The cable shield or braid should be connected to the terminal: 

i *Data wires and the shield wires should be cut as short as possible.*

Internal relay dry contacts

The RCT dry contacts for the 3 internal relays R1, R2, and R3 are available on the CPS central controller motherboard on connectors J23, J24, and J25 (Fig. 7).

Working load: 2 A at 250 VAC, 24 VCC.


Associated alarm type: R1 (alarm/fault), R2 (alarm), R3 (alarm).

RS-485 serial link out

Recommended cable:

RS-485 cable: 1 shielded twisted pair, 100 Ω . (Fig. 6).


MOTHERBOARD FOR RACK-VERSION CPS



Overview of the Motherboard

Part	Connector function
(1)	110-240VCA main power supply (rack version)
(2)	24 VDC external power supply connection
(3)	110-240VCA power supply for (wall-mount) power supply module
(4)	24 VDC power supply output for power supply module <i>motherboard + integrated printer (rack-version option) power</i>
(5)	Internal contact relay outputs (RTC) <i>dry contacts, potential free</i>

Part	Connector function
(6)	Digital addressable modules <i>8 line connectors for connecting digital modules (CPS 10 – CPSRM – CPSDI16 – CPSA04)</i>
(7)	RS-485 digital output <i>links to a supervision system</i>
(8)	USB serial interface <i>(PC/COM_CPS connection for configuration)</i>
(9)	RS-232 serial interface link <i>PC/COM_CPS connection for configuration, External serial printer connection</i>
R1, R2, R3: central station shared internal relays	




The wall-mounted version connects directly to the power supply board.

Inspecting the digital buses

Bicolor (red/green) LEDs located above each line start, on the motherboard, allows for inspection of the bus links as follows:

LED appearance	Status
Red + Green LEDs lit (LEDs blink rapidly, almost imperceptibly) Orange in appearance	Normal operation. Red LED → question Green LED ← response
Red LED blinks once per second (green LED is off) Red in appearance	Communication fault. Missing or faulting module.
Irregular blinking	Poor communication quality
Both LEDs off.	No active modules




Mini-switches

Mini switch A allows the CPS controller to download and read the user program. When the switch is in the “MEM” position (open padlock), the user program memory is accessible and the message “switch open” is displayed on screen. The CPS central controller waits to download the program from the *COM_CPS* software. The CPS central controller goes into “shut-down” mode when mini switch A is in the “MEM” position.

When the *COM_CPS* software programming is complete, the mini switch should be flipped back to the “Prog” position (closed padlock), and the central controller should be rebooted to initialize all of the newly loaded settings.

Mini switch B only used for the central controller’s internal microprocessor. It should always be in the “Run” position.



COM_CPS

Internal relay and buzzer

The CPS central controller is equipped with **3** internal **relays** [R1, R2, R3] and a shared **Buzzer**. The operating settings for the relays and the buzzer can be set with the *COM_CPS* software (see table below).

The internal buzzer is activated when a specific program-defined event occurs (fault or alarm). All lines share relays R1, R2, and R3.

The buzzer’s pitch will vary according to the alarm threshold. Alarms 1 and 2 have the same frequency. Alarms 3 and 4 have a different pitch, allowing the operator to distinguish between alarm levels.

The buzzer can be disconnected by removing the “buzzer activation strap” (J10) located on the motherboard next to the buzzer (cf -: Overview of the Motherboard).

Function / Component	Relay R1	Relay R2	Relay R3	Buzzer
AL 1	X	X	X	X
AL 2	X	X	X	X
AL 3	X	X	X	X
AL 4	X	X	X	X
Module error		X	X	X
System fault*		X	X	X
Out of Range and Fault	X	X	X	X
Positive security		X	X	

*: (System fault) alarm is triggered if there is a communication fault between modules, a short-circuit in a power supply line, or a module inversion.

X: Function can be activated or deactivated

■: Default configuration setting, cannot be changed by user.

USB / RS-232 serial connectors

The CPS central controller is equipped with a serial port which are used to:

- download the user software (see *COM_CPS* instructions);
- program the integrated micro application according to the position of mini switches on the board (factory setting).

i The serial port has 2 interfaces: USB and RS-232. Only one can be used at a time.

The settings for the central controller can be modified after the program has been created. (Use either the USB or RS-232 adapter to connect the PC to the CPS central controller).

(See Chapter 7 – Program transfer).

USB Interface (1)

Use a USB cable to connect the PC to the CPS central controller running the *COM_CPS* application.

The USB interface emulates a serial port and is preferable to an RS-232 serial connection.

The corresponding USB driver must be installed before the PC is connected to the central measuring station (see *COM_CPS* instructions).

SUB-D 9 RS-232 Interface (2)

Use a cross-over RS-232 serial cable to load the user software.

RS-232 cable series reference number:
6 116 026


A serial printer can be permanently connected.

This would allow you to load the software via the USB interface without disconnecting the printer.

RS-485 serial connection (3)

The RS-485 serial port (3) is reserved for the supervision system and is composed of an RS-485 interface using JBUS/MODBUS protocol.

A table containing all of the important information pertaining to the central controller can be found in the **corresponding annex of Chapter 8**.



Printer (Optional feature)

Connection: Central controller RS-232 interface via an RS-232 serial cable.

Communication settings: 19200 Bd, 8 bit, no parity.

Event printing “on the fly.”

Status table printing (choice of four printing schedules). *For example: average readings over 20 minutes, 1 hour, or 8 hours, summary of alarm and relay statuses.*

“Out of paper” functionality: no data is lost when the printer runs out of paper. Once more paper has been loaded, printing will resume where it left off.

Data flow is managed as follows: XON/XOFF Protocol

The printer is ON

The central controller sends data to the printer on start-up. If the printer’s power supply fails or if the RS-232 cable is disconnected, data sent from the central controller will be lost.

In the event that the RS-232 cable becomes disconnected, it may be necessary to turn the printer off and on again to reinitiate data transfer.

The printer is OFF

No data is delivered to the printer. The central controller stops sending data when the printer signals the CPS central controller that it is no longer available (Buffer is full, out of paper, or printing stopped with the ON/OFF button).

The central controller will reinitiate data transfer once the printer signals that it is available (empty buffer, or signal through the printer’s ON/OFF button or online button).


The front panel circuit

The central controller front panel circuit is equipped with:

1 LCD display: backlit, 2 lines by 32 characters and a pictogram line for viewing sensor readings and the zone in question, various test point data, settings, events, etc.

3 lights on the front panel of the central controller (green for power, yellow for errors, and red for exceeding thresholds) serve as constant system status indicators.

7 keys to select on-screen information and/or validate certain operations via menus. The menus are available in English, French, German, Spanish and Dutch.



Display Screen

	No alarms or errors
	Icon associated with one or more alarm icons indicates (by blinking) that the associated alarm is an averaged alarm.
	SOLID = instantaneous alarm 1 BLINKING = averaged alarm 1 (takes priority over solid state)
	SOLID = instantaneous alarm 2 BLINKING = averaged alarm 2 (takes priority over solid state)
	SOLID = instantaneous alarm 3 BLINKING = averaged alarm 3 (takes priority over solid state)
	SOLID = instantaneous alarm 4 BLINKING = averaged alarm 4 (takes priority over solid state)
	SOLID = stable signal in hysteresis interval (calculated over 1 minute)
	SOLID = signal increased in relation to the minute before BLINKING = Exceeding the scale (takes priority over solid state)
	SOLID = signal decreased in relation to the minute before BLINKING = Negative fault (takes priority over solid state)
	SOLID = buzzer on
	SOLID = calibration underway
	SOLID = LS (low speed) relay control active
	SOLID = HS (high speed) relay control active
	SOLID = Error
	SOLID = mains power supply OK BLINKING = battery or mains power supply problem

Keys

	Keys primarily used to modify values (ex: line number)
	Keys primarily used to navigate menus or to change variable current (ex: go from line number to sensor number)
	Key used to validate a menu or an input that would alter system operation. (ex: activation of a relay)
	Key used to return to a previous menu screen or to cancel a selected value before it has been validated.
	Key used to acknowledge a locked alarm (programmed for manual acknowledgement) or to dismiss a buzzer relay after its holding time, even if an alarm is still active.

Lights

Green LED: power supply status indicator SOLID = OK BLINKING = power supply problem (no power to main or problem with the battery pack)	
Orange LED : indicates the presence of one or more faults.	
Red LED: signals the presence of one or more alarms.	

Alarm thresholds

Six alarm thresholds can be programmed and adjusted for each sensor:

Alarm 1, Alarm 2, Alarm 3, Alarm 4, Out of Range and Fault.

Alarms 1 – 4 can be:

- **Instantaneous;**
- **delayed** (0 to 3,600 seconds);
- **averaged** (period of 1 to 480 minutes).

This makes it possible to **calculate STEL and TWA values**.

So, for example, you could choose to activate Alarm 1 if the average calculated levels over a period of *8 consecutive hours* exceeded *50 ppm*, and Alarm 2 if average levels over a period of *10 minutes* exceeded *100 ppm*, and Alarm 3 if the *instantaneous reading* exceeded *200 ppm*.

Averaged alarms are only triggered at the end of a complete time interval.

If the line or the detector module stops, average value calculations are halted and will only begin again once the line or the detector module has been reactivated.

Both the instantaneous and averaged alarms can be set to trigger on an increasing value (rising edge) or on a decreasing value (falling edge).

- **Rising edge:** alarm is activated when levels increase. Use this option for sensors measuring Explo, CO, H₂S, etc.
- **Falling edge:** alarm is activated when levels decrease. Use this option for O₂ sensors, for example.

Out of Range alarm: can activate an alarm, a relay, or an LED.

“Verification” option: this option is activated for explosive gases. When a “verification” alarm occurs, the level displayed will be frozen at the maximum value until it is acknowledged (manually or automatically) and on the condition that the gas levels have fallen under the alarm threshold.

Example of ventilator command functionality for CO/NO detection

Alarm threshold	CO (ppm)	NO (ppm)	RESPONSE
Alarm 1	50	25	Ventilators start on low speed
Alarm 2	100	50	Ventilators go to high speed
Alarm 3	150	75	Max speed ventilation + alarm lights in the surveillance area
Alarm 4	200	100	Visual & audible alarms + restricted area access + evacuation orders for individuals in the area

Alarm acknowledgement

Alarms can be rearmed in two ways:



Manual acknowledgement: the audible alarm can only be dismissed after the “Acknowledge” button on the CPS central measuring controller has been pushed; or

Automatic acknowledgement: the audible alarm will be automatically dismissed once the alarm condition has ended.

If an alarm is triggered, a corresponding message will appear on the screen, an audible alarm (BUZZER) is activated, and the red LED on the front panel is illuminated.



Touching the “Acknowledge” button once will remove the message from the screen and will turn off the BUZZER.

Touching the “Acknowledge” button a second time will re-arm the programmed alarms. These alarms will not turn off until the concentration of gas falls below the threshold.

Chapter 4 Digital Modules

View of Digital Modules

SENSOR MODULE CPS 10





PART	DESIGNATION	CO	NO	NO2	EXPLO
A	CPS 10 SENSOR MODULE	6 513 591	6 513 592	6 513 593	6 513 594
1	CPS 10 SENSOR	6 798 301	6 113 331	6 113 332	
2	CPS 10 BOARD	6 451 597	6 451 598	6 451 599	6 451 600
3	SENSOR WASHER	6 136 243	6 136 243	6 136 243	

Part	DESIGNATION
4	Power supply & network connector
5	Configuration switches (Adresses)
6	Calibraton LED
7	Button [sensor replacement]
8	Measurement connector [sensor replacement]
9	Sensitivity adjustment [sensor replacement]
10	Zero adjustment [sensor replacement]
11	6 153 046 CPS 10 Magnetic switch
12	6 136 052 D2 line washer (qty : 0.316)


RELAY MODULES CPSRM4-CPSRM8

Part	DESIGNATION
1	Power supply & network connector
2	Programmable relays (8 or 4)
3	potential free RTC output contact
4	Safety switch + or - relays
5	Configuration switches (Adresses)
6	Logic Input terminals (2 Inputs)




DESIGNATION	CPS RM4	CPS RM8
RELAY MODULE	6 313 962	6 313 963
RELAY MODULE BOARD	6 451 601	6 451 602

LOGIC INPUT MODULE CPS AI16



ANALOG OUTPUT MODULE CPS AO4



Part	DESIGNATION
1	Power supply & network connector
2	Logic input terminal (16 Inputs)
3	Configuration switches (Adresses)
4	Module board

DESIGNATION	CPS AI16	CPS AO4
MODULE	6 313 964	6 313 980
MODULE BOARD	6 451 603	6 451 614


Connecting Digital Modules

General topology of the RS-485 network

Modules are connected in "parallel" in the RS-485 network, comprised of a 1 twisted pair cable for signals, 1 or more pairs to supply power to the modules, and 1 shield wire.

A 120 Ω end of line resistor (**EOL RESISTOR**) should be placed at the last module in the line, at the end of the bus (see Chapter 6 - End of Line Resistor).

The modules are equipped with a double connector, which can be split to easily connect conductors and also allows you to isolate the module while maintaining line continuity.



Wiring the digital network

The sensor module has two cable glands. One connects to the input wire, and the other connects to the output wire which is routed to the next module.

The modules should be wired with RS-485 shielded twisted pair cable, with a normal impedance of 100 Ω , of at least 0.22mm² in diameter. +24VDC, 0V A and B terminals are linked to +24VDC, 0V terminals A and B in other modules in the line, and then linked to the connector corresponding to the central controller. The cable shield should be connected to a ground terminal marked with the following symbol: (Fig.9).




WARNING

An improper installation can cause incorrect gas level readings or system failure.

Do not run cable near equipment such as motors, transformers, or any lines generating a large magnetic field.

Always check to ensure that the cables are completely separated from other circuits.

i Do not leave any stripped wire ends exposed. To guard against electromagnetic disturbances, the data cables and the screen (tress) cables should be cut as short as possible



Configuring the communication settings

Slave address

All modules in a line should be identified with a unique slave number. Switches 1-5 on the **Configuration Switches** unit (Fig. 10) contained in each module, allow you to set a binary numerical address (1...32).

Possible combinations are listed in the address table below.

Notes: The physical address of a module (1...32) should be identical to the address recorded in the central controller configuration program with COM_CPS.


When replacing a module, set the configuration switches in the new module to the same position as those of the module being replaced.

i Switches 6 (FRAME FILLING) and 7 (DELAY) should be in the OFF position (unused options).

End of line resistor

The last module in each line should be equipped with an end of line resistor.).

i This switch should be in the OFF position for all other modules in the line.



Address Table

Slave Address	SWITCHES				
	ON = 1 ; OFF = 0				
	1	2	3	4	5
1	1	0	0	0	0
2	0	1	0	0	0
3	1	1	0	0	0
4	0	0	1	0	0
5	1	0	1	0	0
6	0	1	1	0	0
7	1	1	1	0	0
8	0	0	0	1	0
9	1	0	0	1	0
10	0	1	0	1	0
11	1	1	0	1	0
12	0	0	1	1	0
13	1	0	1	1	0
14	0	1	1	1	0
15	1	1	1	1	0
16	0	0	0	0	1

Slave Address	SWITCHES				
	ON = 1 ; OFF = 0				
	1	2	3	4	5
17	1	0	0	0	1
18	0	1	0	0	1
19	1	1	0	0	1
20	0	0	1	0	1
21	1	0	1	0	1
22	0	1	1	0	1
23	1	1	1	0	1
24	0	0	0	1	1
25	1	0	0	1	1
26	0	1	0	1	1
27	1	1	0	1	1
28	0	0	1	1	1
29	1	0	1	1	1
30	0	1	1	1	1
31	1	1	1	1	1
32	0	0	0	0	0

CPS 10 Detector Module

The CPS central controller accepts 10 types (or 10 different configurations) of sensors. The type of sensor used in the module depends on the gas being monitored. Electrochemical sensors are used to measure CO, NO, NO₂, for example, while catalytic sensors measure gases such as GPL, CH₄, and H₂).

Available Detector Types

Sensor	Measurement	Sensor life expectancy
Carbon monoxide	CO : 0 ... 300 ppm	36 months
Nitric oxide	NO : 0 ... 100 ppm	24 months
Nitrogen dioxide	NO ₂ : 0 ... 30.0 ppm	24 months
Methane	CH ₄ : 0 ... 100 % LEL	48 months
Liquefied petroleum	LPG : 0 ... 100 % LEL	48 months
Hydrogen	H ₂ : 0 ... 100 % LEL	48 months

Sensor module fault

In the event of a sensor module fault, gas levels are no longer taken into account, and all alarms are cancelled, except for the negative threshold (or fault) which is activated. Average values are no longer taken into consideration and the calculation of average values is paused.

If a sensor faults, it can be replaced while the central controller is still running (hot swap) without replacing the detector.

Detector settings

The following settings apply to each type of detector:

- **The abbreviated name to be displayed on the central controller:** NO, CO, CO₂...
- **The name of the gas:** Carbon monoxide, Nitric oxide, Oxygen, Methane ...
- **Unit:** ppm, LEL, %v/v ...
- **Range** with display format: 100, 10.0, 1.00, ...
- **Actionable thresholds:**
 - o 4 instantaneous thresholds: 0-100% measuring range,
 - o 4 averaged thresholds : 0-100% measuring range, (time interval programmable from 1 to 480 minutes).

If the operating time is inferior to the averaging time interval, the averaging time interval is ignored.

An instantaneous threshold is associated with an averaged threshold to generate an alarm. These two thresholds can be set to trigger on the rising edge (increasing alarm) or the falling edge (decreasing alarm).

Alarm delays (0s to 60 min):

Each of the 4 alarm thresholds can be delayed. If gas levels are in excess of an alarm threshold for an amount of time inferior to the programmed delay, the alarm will not activate.

The alarms can be acknowledged automatically once the alarm is turned off, or manually when the gas levels are once again under the threshold.

Fault thresholds:


- o “underscale” negative signal (exceeding the lower threshold): -10% of the range.
- o “SUP” out of range (exceeding the upper threshold): +120% of the range.
- o “Verification” for all explosive gas sensors, in case an LEL threshold is passed, the SUP alarm remains on even after levels fall under the threshold. The fault alarm is also triggered.

Hysteresis:

Max. 1% of range. Default value = 0%.

Example (see opposite page):

Measurement range = 300 ppm; Alarm = 100 ppm;
Hysteresis (1% of range) = 3 ppm
Level at which alarm can be dismissed = 97



External relay module

The relay module is available in two versions: CPS RM4 (with 4 relays) and CPS RM8 (with 8 relays). It also has two logic inputs (LI) which can be activated.

In maximum configuration, the CPS can manage 256 relays (ex: 32 modules with 8 relays each). For more information about the logic inputs: see: Logic inputs module.

The relays are individually programmable. The operation of each relay depends on its configuration and its function.


Each of the 6 sensor alarms [AL1 - AL2 - AL3 - AL4 - Out of Range - Fault] can control one or more of the 256 relays. Several events can be linked to one relay.

In case of a module relay fault, all relays of this module are restarted.

The CPS central controller will change the relay status unless they belong to a different module type. Restarting will resolve the problem.

Relay status lights


Each relay has a red LED to indicate its status	
Red LED appearance	Status
DEL lit	Activated relay (alarm condition exists)
DEL off	Non-activated relay (no alarm condition)



“Positive/negative” relay security

In addition to switches of CONFIGURATION, RELAY MODULES INCLUDE SWITCHES OF POSITIVE AND NEGATIVE SECURITY CONFIGURATION. Flip the switch to **ON (positive security)** or **OFF (negative security)** as desired. Each switch acts on its corresponding relay (switch 1 → relay RL1, switch 2 → relay RL2, etc.). (Fig. 11).

Note: Only switches 1-4 are active in the CPSRM4 module.



“Normal” relays

The relay is activated when an alarm occurs and is deactivated when the alarm condition ends.

The variables acting on a relay in alarm status are:

- Alarm delay
- Automatic / Manual acknowledgement
- Forced state change via the CPS menu
- Forced state change via a logic input command

“Buzzer” relays

The “Buzzer” relay is used to control an audible alarm.

It can be re-armed with the [**Acknowledge**] key on the central controller, even if the alarm condition has not changed.

The occurrence of a new alarm will reactivate the relay and reset the delays.

The “Buzzer” relay can be automatically dismissed before the end of the alarm with a 15 to 900 second delay (standard setting for “Buzzer” relays) or manually, even if the alarm condition has not changed. It can be configured with a minimum operating time of 1 sec. to 5 min.

The variables acting on a relay after an alarm has occurred are:

- Alarm delay
- Automatic / Manual acknowledgement
- Forced state change via the CPS menu
- Forced state change via a logic input command

Alarm and/or “Buzzer” relay delays

Alarm delays		Relay delays
Instantaneous Alarms	Averaged Alarms	“Buzzer modes”
1 ... 3600 seconds	1 ... 480 minutes	Min. activation time: 0 ... 300 seconds
		Acknowledgement time: 15 ... 900 seconds
Standard settings for each sensor type		Standard settings for all “Buzzer relays”

“LS/HS” Relays

Low speed (**LS**) relays and high speed (**HS**) relays are always used together, allowing you to control a parking facility ventilation system at two speeds.

LS (low speed) : The relays are designed to control slow ventilator speed (star-triangle configuration for a two-speed ventilator).

HS (high speed) : The relays are designed to control high speed ventilator speed (star-triangle configuration for a two-speed ventilator).


The working logic of the relays defined hereafter, takes into consideration the start-up and shut-down intervals during which very high levels of current may occur, capable of damaging motor windings if phases occur in the incorrect sequence.

“LS / HS” Operation

Requirements: Alarm level 1 < Alarm level 2

The LS relay is activated by Alarm 1

The HS relay is activated by Alarm 2



Phases		Action operation	Default Delay*
T₁	Min. duration LS operation Adjustment(s): [1 ... 32767]	Minimum duration, in seconds, during which the ventilator operates at low speed	5 min.
T₂	HS operation delay Adjustment(s): [2 ... 32767]	Minimum duration for Alarm 2, after which the ventilator switches to high speed	15 min.
T_{R1 R2}	LS/HS transition time 1 second (cannot be changed)	Transition time between Relay 1 and Relay 2 is 1 second (standardized throughout the central controller)	1 sec.
T₃	Min. duration HS operation Adjustment(s): [1 ... 32767]	Minimum duration, in seconds, for the ventilator to operate at high speed. HS relay deactivated if Alarm 1 condition ends	10 min.
T₄	LS-HS stop delay Adjustment(s): [1 ... 32767]	Duration, in seconds, after low or high speed ventilator operation has been stopped, before the ventilator can be restarted at low speed.	10 min.

Time values **T₁**, **T₂**, **T₃** and **T₄** can be modified. When the “**Sensor simulation**” menu is used (see the chapter on the maintenance menu/simulation on page 43) the times are decreased, by default, to 12 seconds, 24 seconds, 36 seconds, and 24 seconds, respectively.

Note: An underscale alarm (= fault) activating a LS or HS relay will force the relay into HS position (with respect to the defined time).

“Forced ventilation” function

This is a forced relay state change via the CPS menu. This function allows you to block or release the HS (high speed) command at specified times.

Forced relay state change via a logic input command

In both cases the response is immediate and priority safety settings are maintained: HS takes precedence over LS, and both relays are shut-down if there are contradicting signals.

Logic Input Module

COM_CPS

This module contains 16 logic inputs, linking priority commands, such as fire extinguishers directly to the central controller.

A maximum of 224 total logic inputs across all modules can be activated.

Example 1: 112 modules having 8 relays each, with activated inputs.

Example 2: 7 modules with 16 logic inputs with activated inputs.

Each input can override all other commands to activate or block up to 256 relays.


Priority inputs

Two levels of input priority can be managed on each module with the *COM_CPS* software.

Priority inputs have control of the other inputs (all of the non-priority inputs are “blocked” when a priority input is activated).

In the event that two different inputs of the same priority level send contradicting orders, the relay is shut-down.

In the event of a fault, the inputs are set to zero.



COM_CPS

Analog Outputs Module

This module is comprised of 4 opto-isolated 4-20 mA analog outputs which can be individually activated or deactivated.

Activated: the output analog signal (4-20 mA) varies, according to the input

Deactivated: the analog output signal will be frozen at 0mA, regardless of the input signal.

Several events can be linked to one output. In this case, the largest analog value will be recopied onto the analog output.

The output module also has two logic inputs (LI), identical to those on the “Logic input” module.

A “slave address” for the module can be set with the “DIP” switch (DIP1).

An analog output OFF command from the central controller corresponds to 4 mA.


An analog output ON command from the central controller corresponds to 20 mA.

Connections:

Analog output module

Example of use with analog output module


Analog output module



Chapter 5

Detailed Menus

Menu Tree



Start-up Phase

No faults or alarms are processed during the first minute after start-up. During this phase, the central controller runs a Checksum test (1), a RAM test (2), a line start-up (3) and a module mapping test with a program stored in its memory.

Voltage builds progressively in the lines. Progress bars show the overall progress for line power-up.

Only the power-up of activated lines is shown (identified by a diamond "◇" during the initial power-up phase, and by a black square "■" at the end.)

An exclamation point "!" indicates a short-circuit line fault. The line can be reactivated through the menu system.

Next, a sensor stabilization phase occurs (4) during which time, the alarms are deactivated.

An inspection phase immediately follows in order to verify that the configuration program set with the **COM_CPS** software correctly maps to the modules installed and activated.

If no errors are found, the program runs normally. If errors are detected, the modules in question will be flagged as faulting.










After the start-up phase, the screen will display information pertaining to the selected mode: **events (a)** or **cyclic (b)**. The central controller begins to process data coming in from the various modules.

In cyclic display mode, when no alarms are triggered the levels from each sensor are displayed on the first line of the display screen.

In case of a power outage, the program configuration will be saved. When the controller is turned on, the last program installed by **COM_CPS** will be loaded.

If a sensor faults, the message "Def" will replace the reading value. If the power supply is interrupted within a line, the two points in front of that line will blink. Identify the problem by touching the [ESC] key to display the error message.

If the gas level exceeds a high or low threshold, "Ovs" will appear on the display screen where the value for that sensor would normally appear. This message will display simultaneously with a blinking arrow (pointing up or down, depending on the situation).



Control Menu

Normal Display

Alarm pictograms will appear and disappear in along with the alarm conditions detected by a given sensor. The display shows gas level readings, which may not always be identical to the status of a relay. Under normal conditions, alarm pictograms reflect relay status.

Example: LS and HS relays are configured to run on a delayed trigger. Pictograms do not take this delay interval into consideration. So it is possible that the LS or HS relay is on, while the alarm pictogram does not display on screen, due to the alarm delay.

Cyclical display

This menu allows you to view all of the activated sensors on screen, at a display rate of one sensor every two seconds.

Event display

This menu allows you to view the status of all sensors in alarm mode, faulting, or in calibration, at a rate of one sensor every two seconds.

Sensor Display

This menu allows you to freeze the display on a specific sensor by selecting the line and the module number (The program automatically selects active sensor modules).

Touching the [OK] key once will bring up the sensor name, the abbreviated gas name, the gas level and unit of measure (ppm, % LEL, %v/v).

If the sensor is faulting, "Def" will display in place of the level reading.

Select the line or the sensor (if applicable) using the [◀] [▶] (horizontal) keys.

Select the line number or the sensor number (if applicable) using the [▲] [▼] (vertical) keys.

Press [OK] to select the sensor.

Press [OK] a second time to display both the gas reading level and the 4 averaged readings if average readings were activated. If averaging was not activated, < *** > will display on screen.

If a communication fault occurs, the value will be replaced by < *** > and the averages will stop on the last calculated value.

For all other faults, the gas level will be displayed in order to help the user identify the problem.

☺
Control
13:18:19

☺
Control
Scan & Display

☺
Affichage normal
Display on events

☺
Scan & display
Cyclic display

☺
Control
Sensor Display

☺
Line : 2 Sensor : 1
CPS 10 CO zone 45

☺ ➔
L2, Mod : 1 = 0 ppm CO
CPS 10 CO zone 45

☺ ➔
L2 C 1 Avg. 1: *** 2: ***
0 ppm 3: 0 4: ***

☺ 🔧
L2 C 1 Avg. 1: *** 2: ***
*** ppm 3: 0 4: ***

☺ ⚡
L2 C 1 Avg. 1: *** 2: ***
-37 ppm 3: -1 2 4: ***

Events

This menu can be used to search through a history of the most recent 1,200 events. A record of these events can be printed. State changes are recorded in the history.

If Alarm 1 ends and Alarm 2 is triggered, AL2 ON will be recorded.

Examples:

- (a) The shut-down of a line causes the shut-down of alarms and relays for that line.
- (b) The "fault" alarm is triggered for module 3, line 1.

Other examples:

Module 2, line 8 turned on

30/06/06 (day/month/year) 14:40:36 L:8, Mod:02
Module ON

Alarm 2 triggered

30/06/06 14:49:37 L:8, Mod:02
Alarm 2, OFF ⇒ ON

State change for Relay 2 (command relay)

30/06/06 14:49:37 L:8, Mod:29

Relay 2 Normal ON

Conditions for Alarm 2 end

30/06/06 14:51:03 L:8, Mod:02
Alarm 2, ON ⇒ OFF

Acknowledgement action

30/06/06 14:55:21

ACKNOWL

State change for Relay 2 (relay shut-down)

30/06/06 14:55:21

Relay 2 Normal OFF

Relay Status

This menu displays the status of a relay in a given module. Increments for the preceding and following modules in the line are automatically calculated.

Display the status for the selected relay by pressing the [OK] button. This screen will show the module, its mode of operation (Normal, Buzzer, LS, HS,...) and its status (ON, OFF).

(a): (LS / HS) - Delays

(a): (Buzzer Relay) – Acknowledgement time

(b): (Buzzer Relay) – Min. activation






4-20 mA Output Status

This menu displays the outputs for the selected module. The value is displayed in mA.

Multiple inputs can be linked to one output. In this case, the largest analog value will be recopied onto the analog output.

Activated analog output: the 4-20 mA output signal varies according to the input.

Deactivated analog output: the 4-20 mA output signal will be frozen at 0mA, regardless of the input signal. The output current for each channel will vary between 0 and 24.5 mA.



Printing

“System status” Report

This menu is used to initiate the printing of system status reports. The second part indicates the fault status for all of the modules in each line. Each hexadecimal number corresponds to a module, with Module 1 being on the left, and Module 32 on the right.

0 = OK
1 = Communication error
2 = Module recognition error
4 = Fault triggered by a module fault word.
X = (no programmed module)



If the system detects an abnormality in either the name or the range of a gas, the letter N will blink on the screen

“Status for all line modules” Report

Sensor module: the printed reports will contain both the reading and the averages if averages are activated.

Relay module: the printed reports will contain the status of each relay and of each relay's logic inputs.

Logic inputs module: the printed reports will contain the status of all logic inputs.

“Module status” Report

Prints the status of every module in the selected line. See previous paragraph.

“Printer On/Off” Report

Use the [▲] and [▼] keys to activate or deactivate the printer.

When the printer is activated, the **COM_CPS** cannot be used to for reading or configuration. The configuration mini-switch (A) must be placed in the open padlock position to enable communication between the serial port and the **COM_CPS** software (cf “Programming mini-switches”).

“Event” Report

This feature allows you to print all of the most recent events stored in memory (up to 1,200).

Calibration Report: The calibration data for a sensor is only printed at the end of the calibration process. The record will consist of a title, the line number and module number and 6 readings if a complete calibration has take place:

<i>Calibration1</i>	
<i>Sensor 4 01 CO</i>	
<i>Xo1 = 00004</i>	<i>Zero value before starting procedure</i>
<i>Xo2 = 00000</i>	<i>Zero value</i>
<i>Xo3 = 00000</i>	<i>Zero value after procedure</i>
<i>Xf1 = 00095</i>	<i>Value of the concentration of calibration gas</i>
<i>Xf2 = 00100</i>	<i>Value of the response to the gas</i>
<i>Xf3 = 00100</i>	<i>Value of the reading at the end of the procedure</i>

Access code

An access code is required to access certain menus. The access code is made up of 4 hexadecimal numbers. If the wrong code is entered three consecutive times, the code will be deactivated until all menus have been exited or until after 10 minutes of inactivity. The **COM_CPS** software can be used to modify the access code.

The default access code is: **1 0 0 0**

System Menu

Line, Module, Relay Action

Enter the access code by using the [^] [▼] and [◀] [▶] keys.

Line activation

The selected line is displayed along with its number and name.

To go to a different line, use the [^] [▼]. Change the status by pressing the [OK] key, and then pressing the [◀] [▶] keys, followed by [OK].

If the line is shut-down, the line number will flash intermittently with a cross sign. If the module does not correspond with the CPS central controller COM_CPS-created program, its status is reported as faulting.

Notes: *If the line is shut down by the COM_CPS software, it is impossible to turn it on.*

A line is fully activated approximately 5 seconds after start-up.

A thermal fuse protects the line's power supply from short-circuits. Should a short-circuit occur, a fault word will appear in the menu and an error message will be recorded in the event log. After the short-circuit, the line must be reactivated via the menu.

Relay activation

Use the same "Relay Status" menu to select a relay. After pressing [OK] to select the relay, you have three options:

- < Normal > = Relay functions normally (triggered by alarms)
- < ON > = Relay in forced operation (can only be shut-down by a logic input)
- < ON > = Relay in forced shut-down (can only be turned on by a logic input)

Special case: LS and HS relays

For safety reasons, deactivating a LS or HS relay via the CPS central controller shuts down of the two relays and restarts their timing devices.

If a logic input or a command from the CPS central controller activates a LS or HS relay, the relay will be activated. The relay's activation time is set to the maximum value. In other words, the forced relay shut down ends when logic inputs no longer command the relay or after the end of an alarm condition which could control the relay.

Similarly, if an alarm triggers a HS relay, a LS relay cannot be activated.

The forced activation of a HS relay takes priority over scheduled HS freezes.

☺

System

17: 23: 17

☺

System

Activation line, module, relay

☺

0000 access

☺

Activate Line

☺

Line : 1 OFF

Zone 1

☺

Activate Module

☺

Line : 1 Module : 1 OFF

CPS 10 CO zone 21

☺

Activate Relay

☺

Line : 2 Module : 1

Relay module level - 1

☺


Relay Nr 1 : OFF 0

2-1-1 Low S 0



Activating analog outputs

Choose the 4-20 mA output for the selected module. Pressing [OK] will force a start-up or shut-down for the 4-20 mA output.

- The shut-down freezes the output at 4 mA.
- The start-up freezes the output at 20 mA.



Output4 – 20 mA



Date and Time

⚠ Changing the time settings will reinitialize LS and HS delays!

Example: *If the HS relay is activated and the time is changed, the HS relay will stop so that the LS relay can operate according to the predetermined delays.*




System
Date and hour





Date?





Date (DD: MM: YY)



Hour?






Hour:0 9: 3 6

0 3/ 0 7/ 0 7



Start-up Configuration

This menu is used to select which menu will display by default upon start-up and after 10 minutes of keyboard inactivity.

The two menu options are:
Cyclical Display and Event Display.




System
Start Config







Start Config
Cyclic Display?









Start Config
Display on events?



Maintenance Menu

Simulation

This menu is used to simulate the alarms for a particular sensor module or to temporarily activate one or more relays (or outputs). After exiting the simulation menu, the sensors and relays (excluding LS and HS relays) revert to their prior state.

Enter the access code by using the [] [] and [] [] keys.

Sensor simulation

Select the sensor module you wish to test. Next, select the delay between each of the alarms to be activated (1-59 sec.). Validate your selections by pressing [**OK**].

The central controller will increase reading levels until they exceed the thresholds for all activated alarms in ascending order +/- hysteresis. During the simulation, the theoretical values are displayed on screen.

During this phase, the other sensors are shut down. However, forced-state lines, modules and relays remain active.

Relay Status Simulation


Select the relay module for the relay you wish to test, then the relay you wish to activate.

Use the same "Relay Status" menu to select a relay. After pressing [**OK**] to select the relay, you have three options:

- < **Normal** > = Relay functions normally (triggered by alarms)
- < **ON** > = Relay in forced operation (can only be shut down by a logic input)
- < **OFF** > = Relay in forced shut-down (can only be shut down by a logic input)


After exiting this menu, the relay will revert to its original state.

Analog Output Simulation




Maintenance

09: 52: 15






Maintenance
Simulation




0000 access




Simulation
! Stop all sensors !








Simulation
One sensor



Sensor display
Line : 1 Detector : 1





Step alarm during 10 sec.

0




Simulation
Relay status



Line : 2 Module: 1



Relay Nr 1 : OFF 0
2-1-1 LS 0

Module Verification

Inspection of all of the parameters relating to a module with a *communication fault*.

☺ Maintenance
Module Control ◀▶

☺ Line : 2 Module: 1 ON
CPS 10 CO niveau-1

E = Status word
D = Fault word
C = Start-up config. word
M = Level for sensor modules or State for logic inputs
T = Temperature
Cal (Value) = Concentration of gas used for calibration
ID = Module fault

☺ →
1 E 8000 D 0000 C 0003 iD 0000
01 M 0 T 33°C Cal 300

Displays useful variables and operating time according to the module type:
(Value) = line voltage
R = Relay status (hexadecimal)
(Value) J = Number of days since last calibration.
0 = X0 for sensor modules.
f = Xf for sensor modules.
U = Wear rate for sensor modules.
CRC = (Cyclic Redundancy Check)
Software version for the module program.

☺ →
1 01 23.10V CRC=EAA5 1J
0= 0.00% f=100.00% U= 0.00%

☺ →
2 01 22.37V CRC=404C
R=00

Dep. (value) H = Time (in hours) during which the sensor exceeded the scale.
Ref: (Value) = Sensor reference.

☺ →
1 01 Dep. 0.0 H
Ref=6514000 6001 001 1.0 Ty0

Retry: (plural form, *retries*) – attempt(s) at retransmission. Used to control the quality of communication with the modules.
(a): represents successful transmission attempts. This number increases continually and should be as large as possible.

☺ →
1 5813939 (a) 4 (b)
01 3 (c) 0 (d)

(b), (c), (d): represents next 3 successive retransmission attempts, if necessary, following a failed attempt. In the event that the 1st attempt (1) fails, a 2nd attempt (b) will occur, then a 3rd (c), and 4th (d). The number and the level of saved attempts is indicative of the transmission quality. A large number, on level 3 or 4 is due to poor transmission.

☺ →
Reset retry
0000 acces


Reinitialize “retries” by selecting the “Reset retry” menu.

☺ →
Reset retry
Module 1-01 Line 1 CPS

☺ →
1 0 0
01 0 0

Any module fault generates an event, which is identified by a number (hexadecimal coding) corresponding to the fault type. The number at the end of the second line displays the module error.

The [◀] [▶] keys can be used to change the scroll mode: in normal mode, all events saved to memory are displayed; in default mode, only the faults saved to memory are displayed.



Fault word

4	3	2	1
1 = Def Flash 2 = Def sensor 4 = Low line power 8 = high line power	1 = Def Temp. Min 2 = Def Temp. Max 4 = Def Meas. Min 8 = Def Meas. Max	1 = Def Zero calibration 2 = Def Sens. calibration 4 = Def Zero Sensor replacement 8 = Def Sensitivity. Sensor replacement	1 = Def ROM main memory 2 = Def RAM 4 = Def Battery 8 = module parameter does not correspond to the module card

Sample fault word: **00A0** = Def Sens. calibration + Def Sensitivity. Sensor replacement (A = 10 in hexadecimal = 8 + 2)

Status word

4	3	2 *	1
1 = BitEtatLiss 2 = BitJbFill 4 = BitJbDelay 8 = BitEtatCell **	1 = BitEtatChg 2 = BitEtatPar 4 = BitJbWait 8 = BitJbCar	1 = BitEtat0 2 = BitEtat1 4 = BitEtat2 8 = BitEtat3	1 = BitMod0 2 = BitMod1 4 = BitMod2 8 = BitMod3

**: only for sensor module (indicates presence of a sensor)

2 *	Status
0 (EtatMes)	Normal measure
BitEtat0 (EtatStab)	Stabilization
BitEtat1 (EtatZInit)	Zero init
BitEtat0 + BitEtat1 (EtatStab)	Zero Stabilization
BitEtat2 (EtatZVal)	Zero validation
BitEtat0 + BitEtat2 (EtatSWait)	Sensitivity waiting
BitEtat1 + BitEtat2 (EtatSInit)	Sensitivity init
BitEtat0 + BitEtat1 + BitEtat3 (EtatSStab)	Sensitivity stabilization
BitEtat3 (EtatSVal)	Sensitivity validation
BitEtat0 + BitEtat3 (EtatChg)	Button replace pushed

	Module Designation	Type
1	Sensor CO	0
2	sensorNO	1
3	Sensor NO ₂	2
4	Sensor EXPLO	3
5	Sensor O ₂	4
6	Free	5
7	Free	6
8	Other	7
9	4 relay mod	8
10	8 relay module	9
11	Free	A
12	Free	B
13	4ana output mod	C
14	16 log input mod	D
15	Analog input mod	E
16	Free	F

Bus Faults

This menu displays the faults from all modules in a line. Each hexadecimal number corresponds to a module, with Module 1 being on the left, and Module 32 on the right.

- 0 = OK
- 1 = Communication error
- 2 = Module recognition error
- 4 = Fault triggered by a module fault word.
- X = module missing or unrecognized due to a conflict with another module

Maintenance
Bus default

.Line: 1
021XXXXXXXXXXXXXXXXXXXXXXXXXXXXX

Module 1

Module 32

Line: 1 Module: 1 = OK
Line: 1 Module: 2 = module recognition error
Line: 1 Module: 3 = communication error

Reset maintenance

i Reserved for ISC- maintenance personnel only.

Maintenance
Reset Maintenance

CPS / COM_CPS Version – Available memory level

Displays the CPS central controller version as well as the COM_CPS programming software version.

Displays the microcontroller availability (time) rate (in %). This value will vary somewhat in relation to the program but can detect if a microprocessor is being overtaxed.

COMCPS 1.03 JBUS = 1
CPS 1. 00.00 91. 2% Free

Enter the access code by using the [^] [v] and [l] [r] keys.

Next, press the [OK] key to reinitialize all counters to zero and to refresh the date.

CPS Installation

This menu is used to zero the following two settings across all modules: Last zero date

Operating Time

Each module logs its operation time in days. For the sensors, this time is equal to the time since the last calibration or the last zero.

Exceeding the scale

Each sensor logs the amount of time that levels exceed the scale in seconds. Go to the “Module Verification” menu to see this time.

0000 acces

Installation CPS
26 / 06 / 07

Program transfer

This chapter describes the transfer of data from the *COM_CPS* application to the CPS, and vice versa (see the *COM_CPS* user's guide). After launching the software, you will see a welcome window.

PC → CPS transfer

Once the program has been created, the central controller should receive new settings..

Step 1: establish a physical connection

- 1) Use either the USB or RS-232 adapter to connect the PC to the CPS central measuring controller.
 - 2) Ensure that the CPS central measuring controller is connected to a power source.
 - 3) **On the central controller:** flip the programming switch to the "MEM" position. The message "Switch open – Program..." will appear on the display screen. Communication with the central controller is authorized during this phase..
-

Step 2: link configuration

- 1) In the menu bar, select [Communication > Port].
- 2) Select the port [COM x] to use on the PC.

Note: communication speed is selected automatically.

Step 3: data transfer

- 1) In the menu bar, select [Transfer > from PC to CPS].The message "Flip switch to MEM position in order to reprogram the central controller" refers to the <MEM> position on the CPS central controller commutator before starting the transfer procedClick [OK] once verification has ended.
 - 2) During the transfer, a progress bar will indicate transfer progress.
 - 3) Once the transfer is complete, the message "Operation complete" will appear on screen. Click [OK]. The configuration program has been transferred from the PC to the CPS central controller.
 - 4) **On the central controller:** The message "Switch open – Complete" will appear on the display screen. Flip the programming switch to the "Prog" position.
 - 5) The central controller will perform a "Start-up" procedure.
-

CPS → PC transfer

Step 1: establish a connection

- 1) Use either the USB or RS-232 adapter to connect the PC to the CPS central controller.
 - 2) Ensure that the CPS central measuring controller is connected to a power source.
 - 4) **On the central controller:** flip the programming switch to the "MEM" position. The message "Switch open – Program..." will appear on the display screen. Communication with the central controller is authorized during this phase.
Or, use the "Control" menu to set the printer to "OFF."
-

Step 2: link configuration

- 1) In the menu bar, select [Communication > Port].
- 2) Select the port [COM x] to use on the PC.

Note: communication speed is selected automatically.

Step 3: data transfer

- 1) In the menu bar, select [Transfer > from CPS to PC].
- 2) The message, "Do you want to read the CPS central controller configuration?" will appear onscreen. Click [OK]. If the message, "Check port configuration and ensure printer set to OFF position and try again" appears, verify that the CPS printer is in the OFF position.
- 3) Select the folder where you want to download the file, and create a file name (a default name is suggested).
- 4) During the transfer, a progress bar will indicate transfer progress.
- 5) Once the transfer is complete, the message "Operation complete" will appear on screen. Click [OK]. The data has been transferred from the CPS central controller to the PC.
- 6) **On the central controller:** The message "Switch open – Complete" will appear on the display screen. Flip the programming switch to the "Prog" position.
- 7) The central controller will perform a "Start-up" procedure.

Error messages

Error messages will appear in the following scenarios:

ERR 01: Module fault relating to the program.

The test runs systematically on start-up and periodically when a module is activated by the menu if the module does not correspond to the loaded program. The error remains until the problem is corrected or until the module is shut down.

ERR 02: Fault word reading for a module. Name displayed on the 1st line of the screen.

ERR 04: Power line error.

ERR 08: I2C (real-time clock) or EEPROM error.

ERR 10: Module communication error.

ERR 20: Problem originating at printer. Printer shut-down or lack of paper.

Checksum error

When the central controller starts up, checksum values appear briefly on screen after the display test. The value calculated by the central controller is displayed on the first line, and the checksum calculated by the PC with the COM_CPS software is displayed on the 2nd line.

If these two values are different, this screen will remain on the display screen, indicating that there is a problem (example: depleted battery.) The user program protection switch must be flipped, and a new COM_CPS program must be transferred.

Flip the switch back into the “closed padlock” position before restarting the central controller.

Example of an error

Operation before event



CPS Analysis 21:04
Parking Charles de Gaulle

Technical alarm triggered (fault).
buzzer engaged (if activated),
Front panel yellow LED illuminated.
Two pictograms appear: the blinking
“maintenance key” and the “siren.”



CPS Analysis 21:04
Parking Charles de Gaulle

Action on the front panel “acknowl” button.
Audible alarm (buzzer) is off.
“Siren” pictogram disappears.
“Maintenance key” pictogram remains on screen.
Front panel yellow LED illuminated.



CPS Analysis 21:07
Parking Charles de Gaulle

Action on the “acknowl” button.
Direct access to the “ERRORS” data page.
ERR 11 = ERR 10 + ERR 1
Communication fault for Module 1, Line 2.
Check the line and/or the module. The fault will
disappear when the problem is resolved.



Relay module level-1
ERR11 : Com. 2 01

If multiple errors occur, all of the error codes will be displayed one after another. The faulting modules for each error will be displayed one at a time by their line number and module number.

For all faults except for communication faults, the gas level will be displayed in order to help the user identify the problem.



Sensor CO 1, level-1
ERR01 : Type 2 01 Meas=x.x

Testing and calibration of stable installations

Warning : The setting of this section are reserved for authorized persons formed because they might call into question the reliability of detection.

The site responsible is required to establish security procedures on its site. OLDHAM may be not responsible for their implementation.

Gas detectors are above all safety instruments. In consideration of this, **OLDHAM** recommends regular planned testing of fixed gas detection installations.

A functional test involves injecting a sufficient concentration of gas at the sensor level to trigger pre-set alarms. This test does not replace a full sensor calibration under any circumstances.

The frequency of gas tests depends on the industrial application in which the detector is in use. Frequent inspections should be made in the months following the commissioning of the installation, and then become more widely spaced provided that no significant deviation is observed.

If a detector should fail to react when in contact with the gas, calibration is essential. The frequency of calibrations is a function of the results of the tests (humidity, temperature, dust, etc.). However, it must not exceed one year. It is also advisable to calibrate the sensor after exposure to high concentrations of gas.

Gas concentration which must be used during manual or semi automatic calibration

- CPS 10 **CH₄** = 2.5% CH₄/air
- CPS 10 **H₂** = 2% H₂/air
- CPS 10 **C₄H₁₀** = 0.9% C₄H₁₀/air
- CPS 10 **CO** = 100ppm
- CPS 10 **NO** = 50ppm
- CPS 10 **NO₂** = 10ppm


Sensor replacement

Sensors should be replaced as a part of regular preventative maintenance or following a failed calibration test.

After replacing a sensor, a calibration test must be conducted (see the chapter on semi-automatic calibration).

To replace a sensor:

- Remove the sensor cover.
- Hold down the sensor replacement button (1) for **5 seconds**, until the solid green LED (2) is on.
- Release the button.
- Replace the sensor and conduct a calibration test (mandatory) according to the semi-automatic procedure.



On the central controller, the “maintenance key” pictogram indicates that the sensor has been replaced. The key will remain on screen until the sensor has been calibrated or until the sensor’s power supply fails. The wear settings for the sensor are initialized upon calibration

☺	↗	i
L:2, Mod: 1 = 0.0 ppm Calib		


Semi-automatic calibration

During a sensor module calibration, the central controller blocks the alarms from the module in question and displays a maintenance key on the screen. Up to 10 sensors can be calibrated at the same time. The concentration level for the calibration gas is stored in the sensor's memory.

Each calibration start and stop is logged as an event.

The printer records a state after the calibration of each sensor (cf : Printing).

If the calibration is failed, the sensor is listed as faulting and an event is logged with a fault code (0010 – calibration zero fault, 0020 = calibration sensitivity fault) .



Manual calibration

The calibration kit provided by ISC must be used (Ref. 6 116 291) female connector / wires / voltmeter connection files).

- Remove the sensor cover.
- Connect the cable (strand) to the circuit's male connector.

Zero adjustment

Ensure that the sensor is in clean air. If not, inject air into the sensor at a flow rate of 60 l/h, then wait for voltmeter levels to stabilize (use the gas injection device: bottle of synthetic air, calibration pipe, tube).

- Adjust the zero with the potentiometer's **"ZERO"** until the voltmeter reads **0 mV**.



Sensitivity adjustments

- Now inject the known gas (60 l/h) into the sensor, and wait for the voltmeter signal to stabilize.
- Adjust the sensitivity if necessary with the potentiometer **"SENS"** until the signal value (in mV) corresponds to the amount of reference gas used. **Use the following formula to calculate the correct value for the signal.**
- Stop injecting gas (remove the calibration pipe from the sensor).
- Wait for the voltmeter to "return to zero."

Version CPS 10 for explosive gas

The CPS central controller has a **"verification"** function: if the sensor measures a concentration of gas higher than 100% LEL, the signal will be dismissed by disconnecting its power supply.

$$U_{(mV)} = \frac{1600 \times \text{Reference gas value}}{\text{Measuring scale}}$$



MAINTENANCE WIRES:

+VCC (red) = + power supply


Signal S (yellow) = signal from 0 mV to 1600 mV for zero and sensitivity measure

Ref 2,5V (brown) = zero reference for signal reading from 0 mV to 1600 mV

GND (black) = electronic circuit ground.




Semi-automatic calibration device



Semi-automatic calibration

The magnetic calibration allows for one-man and non-intrusive calibration to **save considerable time**.


Manual calibration with zero and span potentiometers is possible by opening the CPS 10



Calibration element

Rep	Part number	Nr	Description
1	6 128 972	1	SUPPORT
2	6 155 771	1	MAGNET MEDER CPS 10
3	6 325 161	1	HANDLE
4	6 331 141	1	CALIBRATION CAP
5	6 902 406	3	SCREW PCL TZ M3*10
6	6 903 305	1	SWIVEL H M3

Slug the gas
with a 60L/H discharge



Central controller maintenance

Do not use alcohol- or ammonia-based liquids to clean the central controller. If necessary, clean the exterior of the central controller with a damp cloth.

Lithium battery


If the central controller configuration settings are lost, the lithium battery soldered to the display card must be replaced. This operation should be performed by a qualified professional.

Lithium battery characteristics: VARTA CR1/3N or equivalent.

Back-up battery pack


When the back-up battery power drops, the battery should be replaced. This operation should only be performed by a qualified professional.

The battery pack is located underneath the display screen on the wall-mounted version. Take off the display screen to access the battery pack. Unplug the connector linking the battery pack to the motherboard. Remove the 4 mounting screws. Attach the new battery pack. Plug in the connectors before reassembling the display.



Scrapping of CPS System

Concerning the conservation, of the protection and the improvement of the quality of the environment, as well as for the protection of the health of the persons and the careful and rational use of natural resources, CPS system has to be the object of a selective collection for the electronic equipments and cannot be scrapped with the normal domestic waste. The user thus has the obligation to separate the CPS system of the other waste so as to guarantee that it is recycled in a sure way at the environmental level. For more details of the existing sites of collection, contact the local administration or the distributor of this product.




Chapter 7


Technical Specifications

CPS Central Controller	
CPS w/ metal wall-mounted casing:	Dimensions (mm): 320 x 180 x 95 Degree of protection: IP 54
Cable entries	5 M20 cable glands Diameter 5-12 mm power / local relays. - 9 PG9 1 D-SUB 9 Pin RS-232 cable
CPS rack version	Dimensions: Length: 19" ; Height: 4 U (176 mm) IP class: IP 31
Operating conditions	Ambient temperature: -10°C to 40°C Storage temperature: -20°C to 85°C Humidity: 5 to 95% noncondensing
Power supply	Mains power supply: Voltage: 110-240VCA Battery back-up: Optional – Capacity: 600 mAh 24 V Consumption: 140 mA + 12 mA per measurement line (240 mA max.)
Measuring lines	Number: 8 RS-485 digital measuring lines Line capacity: 32 digital CPS modules (CPS 10, CPS RM, CPS DI16, CPS AO4) ModBus Protocol Cable type: 2 twisted pairs shielded RS-485 4Xawg22 (diameter 0.67mm) cable, 100m Transmission speed: 9600 Bauds (trial with 0.35 mm²) Module power supply: 12 to 30 VCC via the CPS central controller and if necessary via a 24VCC external additional power supply Digital module network: RS-485 ModBus, addresses 1 to 32, set with mini switches Isolation: Power supply / Digital network: 1500 V
Display	Backlit LCD display [2 lines, 32 characters per line - 1 line for pictograms - 3 electroluminescence diodes to indicate operating status: OK, Fault, Alarms]
Keyboard	Membrane keyboard, 7 intuitive keys
Local buzzer	Alarm and fault signaling
Integrated printer	Optional for rack version (no integrated printer option for the metallic wall casing)
Alarms	Number of alarms: 6 alarms per sensor (AL1, AL2, AL3, AL4, Out of Range, Fault + Validation for Explo gas) Programmable thresholds: For instantaneous or averaged values, increasing or decreasing values, or for manual or automatic rearming.
3 Internal local relays	Relay: R1 (alarm/fault) – R2 (alarm) – R3 (alarm). Minimum charge for RCT contacts: 2A / 250 VAC – 30 Vcc (resistive charge) Relays settings are configured with the COM_CPS configuration software. Torque : 0.5-0.6 Nm
Centralized supervision system digital output connections.	
RS-485	ModBus Protocol (connection with a centralized supervision device)
RS-232 or USB	USB protocol priority (permanent connection to system configuration)
Approvals:	
Low Voltage Directive:	This device is in compliance with the security requirements of Directive 73/23/EEC, modified by Directive 93/68/EEC, based on standard 61010-1 and its second amendment.
Metrology:	Underground parking facilities: according to VDI 2053
EMC Electromagnetic compatibility:	according to EN 50270


CPS 10 Sensor Module	
Dimensions (mm):	118 x 110 x 60
Degree of protection:	IP 54
Cable entries:	2 M16 cable glands 4-8 mm diameter
Consumption:	Toxic gas sensor: 2.5 mA in normal operation Explo gas sensor: 50 mA in normal operation
Status indication after calibration	Red/Green electroluminescent diode
Calibration:	Automatic, no need to open the sensor due to a gas introduction device equipped with a magnetic switch, or with a potentiometer inside of the case.
Sensor replacement:	Sensor replacement switch on the interior of the CPS 10 case. Detection of sensor




CPS RM4 or RM8 Relay Module	
Dimensions (mm):	125 x 165 x 60
Mounting:	Ratchets into DIN rail
Number of relays:	4 relays (CPS RM4); 8 relays (CPS RM8) Contact type: RCT
Minimum charge for contacts:	2 A / 250 V over resistive charge
Connection:	Screw posts (cable: 2.5 mm ² max.) Torque : 0.5-0.6 Nm
Consumption:	3.5 mA in normal operation
Bistable Relays. Configuration of positive or negative relay security with mini switches. Relay modules have 2 logic inputs. Configuration via the COM_CPS configuration software.	



CPS DI16 Logic Inputs Module	
Dimensions (mm):	125 x 165 x 60
Mounting:	Ratchets into DIN rail
Number of All or Nothing Inputs:	16
Connection:	Screw posts (cable: 1.5 mm ² max.) Torque : 0.5-0.6 Nm
Consumption:	2 mA in normal operation



CPS AO4 Analog Output Module	
Dimensions (mm):	125 x 165 x 60
Mounting:	Ratchets into DIN rail
Number of analog outputs:	4-20 mA output, max. resistance 500 Ω Isolation galvanique individuelle + 2 entrées logiques
Connection:	Screw posts (cable: 1.5 mm ² max.) Torque : 0.5-0.6 Nm
Consumption under 24V at module input	I < 5 mA if the 4 channels are shut down I < 36 mA if only one channel is activated I < 130 mA if all 4 channels are activated



Chapter 8

Annexes

JBUS/MODBUS Protocol

JBUS Transfer Table

Nda : Relays and inputs are numbered from 1 to 64 and from 1 to 64 In order to optimize the occupation memory in the CPS

Classification is automatically made by the COMCPS in the ascending order of the relays then modules then lines.

Idem for logic input

ADDRESS JBUS	HEXA ADDRESS
1	9C40

Access in read only by bit : Function (1 : 2)		BYTE1		BYTE2		BIT 7		BIT 6		BIT 5		BIT 4		BIT 3		BIT 2		BIT 1		BIT 0		BIT 7		BIT 6		BIT 5		BIT 4		BIT 3		BIT 2		BIT 1		BIT 0	
1	0001	Alarm Status of each detector modules																																			
1	0001	Alarm 1 Status of each detector module		line, Module		2 bytes																															
2	0002					2 bytes																															
3	0003					2 bytes																															
4	0004					2 bytes																															
...	...					2 bytes																															
15	000F					2 bytes																															
16	0010					2 bytes																															
17	0011	Alarm 2 Status of each detector module		line, Module		2 bytes																															
33	...	Alarm 3 Status of each detector module		Idem																																	
49	0031	Alarm 4 Status of each detector module		Idem																																	
85	0041	Alarm overscale Status of each detector module		Idem																																	
81	0051	Alarm fault Status of each detector module		Idem																																	
96	0060																																				

97	0061	Relays Status (delayed one second)																																			
97	0061	relays 1-8		relays 9-16		2 bytes																															
98	0062	relays 17-24		relays 25-32		2 bytes																															
99	0063	relays 33-40		relays 41-48		2 bytes																															
100	0064	relays 49-56		relays 57-64		2 bytes																															
101	0065	relays ...		relays ...		2 bytes																															
112	0070	relays 240-248		relays 249-256		2 bytes																															
113	0071			If bit = 0 relay OFF, if bit = 1 relay ON																																	

113	2071	Module fault	line fault1	module 1	line fault1	module 2	Fault type for the both modules		2 bytes	Starting line L1, M1	Alarm line L1, M1	Intern module L1, M1	Module type L1, M1	Communication L1, M1	BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
113	2071																					
114	2072		line fault1	module 3	line fault1	module 4	idem		2 bytes													
115	2073		line fault1	module 5	line fault1	module 6	idem		2 bytes													
116	2074		line fault1	module 7	line fault1	module 8	idem		2 bytes													
117	2075		line fault1	module 9	line fault1	module 10	idem		2 bytes													
118	2080		line fault1	module 31	line fault1	module 32	idem		2 bytes													
129	2081		line fault2	module 1	line fault2	module 2	idem		2 bytes													
145	2091		line fault3	module 1	line fault3	module 2	idem		2 bytes													
161	20A1		line fault4	module 1	line fault4	module 2	idem		2 bytes													
177	20B1		line fault5	module 1	line fault5	module 2	idem		2 bytes													
193	20C1		line fault6	module 1	line fault6	module 2	idem		2 bytes													
209	20D1		line fault7	module 1	line fault7	module 2	idem		2 bytes													
225	20E1		line fault8	module 1	line fault8	module 2	idem		2 bytes													
240	20F0		line fault8	module 31	line fault8	module 32	idem		2 bytes													
241	20F1		# bit = 0 relay OFF, # bit = 1 relay ON																			

241	20F1	forced operating	relay 1-8		relay 9-16			2 bytes	relay24	relay23	relay22	relay21	relay20	relay19	relay18	relay17	relay16	relay15	relay14	relay13	relay12	relay11	relay10	relay9	BIT 0
241	20F1																								BIT 1
242	20F2		relay 17-24		relay 25-32			2 bytes																	BIT 2
243	20F3		relay 33-40		relay 41-48			2 bytes																	BIT 3
244	20F4		relay 49-56		relay 57-64			2 bytes																	BIT 4
245	20F5		relay...		relay...			2 bytes																	BIT 5
256	0100		relay 240-248		relay 249-256			2 bytes																	BIT 6
257	0101		# bit = 0 relay under normal operating, # bit = 1 relay in forced operating					2 bytes																	BIT 7

257	0101	forced stop						Bit 7	relay24	relay23	relay22	relay21	relay20	relay19	relay18	relay17	Bit 0
257	0101	relay 1-8	relay 9-16					2 bytes									Bit 1
258	0102	relay 17-24						2 bytes									Bit 2
259	0103	relay 33-40	relay 25-32					2 bytes									Bit 3
260	0104	relay 49-56	relay 41-48					2 bytes									Bit 4
261	0105	relay ..	relay 57-64					2 bytes									Bit 5
272	0110	relay 240-248	relay ..					2 bytes									Bit 6
273	0111		relay 249-256					2 bytes									Bit 7

If bit = 0 relay under normal operating, if bit = 1 relay in forced operating

273	0111	Logic input status						2 bytes									Bit 0
273	0111	logic input 25 to 32	logic input 17 to 24					2 bytes									Bit 1
274	0112	logic input 9 to 16	logic input 1 to 8					2 bytes									Bit 2
275	0113	logic input 57 to 64	logic input 49 to 56					2 bytes									Bit 3
276	0114	logic input 41 to 48	logic input 33 to 40					2 bytes									Bit 4
277	0115							2 bytes									Bit 5

277	0115	DC supply lines and errors						2 bytes									Bit 0
277	0115	Alimentation line	Alimentation error					2 bytes									Bit 1

If bit = 1 line problem, otherwise line OK

If bit = 1 line OFF, otherwise line OK

scribi

EXTRA CREDIT

JBUS		Bit 0														
40613	9E41	Detector measures														
40613	9E41	Averaged measure 1	line 1	Module 1												Word
40614	9E42	Averaged measure 2	line 1	Module 1												Word
40615	9E43	Averaged measure 3	line 1	Module 1												Word
40616	9E44	Averaged measure 4	line 1	Module 1												Word
40617	9E45	Averaged measure 1	line 1	Module 2												Word
40641	9EC1	Averaged measure 1	line 2	Module 1												Word
40642	9EC2	Averaged measure 2	line 2	Module 1												Word
40669	9F41	Averaged measure 1	line 3	Module 1												Word
40687	9F-C1	Averaged measure 1	line 4	Module 1												Word
41025	A041	Averaged measure 1	line 5	Module 1												Word
41153	A0C1	Averaged measure 1	line 6	Module 1												Word
41281	A141	Averaged measure 1	line 7	Module 1												Word
41409	A1C1	Averaged measure 1	line 8	Module 1												Word
41536	A240	Averaged measure 1	line 8	Module 32												Word
41537	A241															

JBUS		Bit 0														
41537	A241	Detector measures														
41537	A241	Maximum measure	line 1	Module 1												Word
41538	A242	Maximum measure	line 1	Module 2												Word
41539	A243	Maximum measure	line 1	Module 3												Word
41540	A244	Maximum measure	line 1	Module 4												Word
41541	A245	Maximum measure	line 1	Module 5												Word
41564	A25C	Maximum measure	line 1	Module 28												Word
41565	A25D	Maximum measure	line 1	Module 29												Word
41566	A25E	Maximum measure	line 1	Module 30												Word
41567	A25F	Maximum measure	line 1	Module 31												Word
41568	A260	Maximum measure	line 1	Module 32												Word
41569	A261	Maximum measure	line 2	Module 1												Word
41570	A262	Maximum measure	line 2	Module 2												Word
41601	A281	Maximum measure	line 3	Module 1												Word
41633	A2A1	Maximum measure	line 4	Module 1												Word
41665	A2C1	Maximum measure	line 5	Module 1												Word
41697	A2E1	Maximum measure	line 6	Module 1												Word
41729	A301	Maximum measure	line 7	Module 1												Word
41761	A321	Maximum measure	line 8	Module 1												Word
41792	A340	Maximum measure	line 8	Module 32												Word
41793	A341															

JBUS	41793	A341	Detector measures		Bit 15
	41793	A341	Sentence1	Byte1	Bit 14
	41794	A342	Sentence1	Byte2	Bit 13
	41794	A342	Sentence1	Byte3	Bit 12
	41795	A343	Sentence1	Byte4	Bit 11
	41796	A344	Sentence1	Byte5	Bit 10
	41796	A344	Sentence1	Byte6	Bit 9
	41797	A345	Sentence1	Byte7	Bit 8
	41797	A345	Sentence1	Byte8	Bit 7
	41798	A346	Sentence1	Byte9	Bit 6
	41798	A346	Sentence1	Byte10	Bit 5
	41799	A347	Sentence1	Byte11	Bit 4
	41799	A347	Sentence1	Byte12	Bit 3
	41800	A348	Sentence1	Byte13	Bit 2
	41800	A348	Sentence1	Byte14	Bit 1
JBUS	41801	A349	Sentence1	Byte15	Bit 0
	41801	A349	Sentence1	Byte16	
	41802	A34A	Sentence1	Byte17	
	41802	A34A	Sentence1	Byte18	
	41803	A34B	Sentence1	Byte19	
	41803	A34B	Sentence1	Byte20	
	41804	A34C	Sentence1	Byte21	
	41804	A34C	Sentence1	Byte22	
	41805	A34D	Sentence1	Byte23	
	41805	A34D	Sentence1	Byte24	
	41806	A34E	Sentence1	Byte25	
	41806	A34E	Sentence1	Byte26	
	41807	A34F	Sentence1	Byte27	
	41807	A34F	Sentence1	Byte28	
	41808	A350	Sentence1	Byte29	
	41808	A350	Sentence1	Byte30	

JBUS	41808	A350	Detector measures		Bit 15
	41808	A350	Sentence2	Byte31	Bit 14
	41809	A351	Sentence2	Byte32	Bit 13
	41809	A351	Sentence2	Byte33	Bit 12
	41810	A352	Sentence2	Byte34	Bit 11
	41810	A352	Sentence2	Byte35	Bit 10
	41811	A353	Sentence2	Byte36	Bit 9
	41811	A353	Sentence2	Byte37	Bit 8
	41812	A354	Sentence2	Byte38	Bit 7
	41812	A354	Sentence2	Byte39	Bit 6
	41813	A355	Sentence2	Byte40	Bit 5
	41813	A355	Sentence2	Byte41	Bit 4
	41814	A356	Sentence2	Byte42	Bit 3
	41814	A356	Sentence2	Byte43	Bit 2
	41815	A357	Sentence2	Byte44	Bit 1
	41815	A357	Sentence2	Byte45	Bit 0
JBUS	41816	A358	Sentence2	Byte46	
	41816	A358	Sentence2	Byte47	
	41817	A359	Sentence2	Byte48	
	41817	A359	Sentence2	Byte49	
	41818	A35A	Sentence2	Byte50	
	41818	A35A	Sentence2	Byte51	
	41819	A35B	Sentence2	Byte52	
	41819	A35B	Sentence2	Byte53	
	41820	A35C	Sentence2	Byte54	
	41820	A35C	Sentence2	Byte55	
	41821	A35D	Sentence2	Byte56	
	41821	A35D	Sentence2	Byte57	
	41822	A35E	Sentence2	Byte58	
	41822	A35E	Sentence2	Byte59	
	41823	A35F	Sentence2	Byte60	
	41823	A35F	Sentence2	Byte61	

JBUS	41823	A35F	Random keyboard		Bit 15
	41824	A360	Blank 32bytes		Bit 14
	41855	A37F	Word		Bit 13

CPS – User Manual | Page 65

JBUS		Input 1b1		Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
57681	E151	Module number (1 byte) and input number (1b)	2 bytes																
57681	E151	Module number (1 byte) and input number (1b)	2 bytes																
57682	E152	Input 1 name (20 bytes)	2 bytes																
57692	E15C	Module number (1 byte) and relay function and position (1b)	2 bytes																
57693	E15D	Input 2 name (20 bytes)	2 bytes																
		...																	
80431	EO0F	Module number (1 byte) and input number (1b)	2 bytes																
80442	EC1A	Input 1 name (20 bytes)	2 bytes																

DETAILS AND PARAMETERS OF THE 10 TYPES OF POSSIBLE SENSORS (RESERVE COMICPS)

JBUS		List units of the modules		Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
80462	EC2E	...																	
80462	EC2E	gas name for type 1 (6 bytes)																	
80465	EC31	...																	
80465	EC31	gas name for type 2 (6 bytes)																	
80469	EC49	...																	
80469	EC49	gas name for type 10 (6 bytes)																	
80492	EC4C	...																	

JBUS		Code of detector gas type		Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
80492	EC4C	...																	
80492	EC4C	Gas code for type 1 and 2 (2 bytes)																	
80493		Gas code for type 3 and 4 (2 bytes)																	
80496		...																	
80496		Gas code for type 9 and 10 (2 bytes)																	
80497	EC51	...																	

JBUS		Instantaneous alarm threshold		Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
80497	EC51	...																	
80497	EC51	Instantaneous alarm 1 threshold	Type 1																
80498	EC52	Instantaneous alarm 1 threshold	Type 2																
80499	EC53	Instantaneous alarm 1 threshold	Type 3																
80506	EC5A	...																	
80506	EC5A	Instantaneous alarm 1 threshold	Type 10																
80507	EC5B	Instantaneous alarm 2 threshold	Type 1																
80508	EC5C	Instantaneous alarm 2 threshold	Type 2																
80509	EC5D	Instantaneous alarm 2 threshold	Type 3																
80516	EC64	...																	
80516	EC64	Instantaneous alarm 2 threshold	Type 10																
80536	EC78	...																	
80536	EC78	Instantaneous alarm 4 threshold	Type 10																

JBUS		Enable or disable Alarms															
800657	ECF1																
800657	ECF1	Type 1 (1 byte)					2 bytes										
800658	ECF2	Type 3 (1 byte)					2 bytes										
		...															
800661	ECF5	Type 9 (1 byte)					2 bytes										

800657	ECF1																
800657	ECF1	Type 1 (1 byte)					2 bytes										
800658	ECF2	Type 3 (1 byte)					2 bytes										
		...															
800661	ECF5	Type 9 (1 byte)					2 bytes										

JBUS		Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
60787	ED73	Resume COMAPS															
60787	ED73	Type 1 (1 byte)	2 bytes														
60788	ED74	Type 3 (1 byte)	2 bytes														
		...															
60791	ED77	Type 9 (1 byte)	2 bytes														

[illegible]

JBUS		Bit 15															
		Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
60832	Descriptor type Range																
60832	Range	Type 1	Word														
60833	Range	Type 2	Word														
60834	Range	Type 3	Word														
...														
60841	Range	Type 10	Word														



DECLARATION UE DE CONFORMITE
EU Declaration of Conformity



La société **Oldham S.A.S.**, ZI Est 62000 Arras France, atteste que la
Oldham S.A.S. company, ZI Est 62000 Arras France, declares that the

Système de mesure CPS –Monitoring system CPS

Incluant la centrale de mesure, les détecteurs de gaz, les modules E/S et relais
Including the controller, the gas detectors, the relays and I/O modules

est conforme aux exigences de:
complies with the requirements of the following Directives:

I) Directive Européenne CEM 2014/30/UE du 26/02/14: Compatibilité Electromagnétique
The European Directive EMC 2014/30/UE dated from 26/02/14: Electromagnetic Compatibility

Normes harmonisées appliquées: **EN 50270:06** for type 1&2 CEM-Appareils de détection de gaz
Harmonised applied Standards EMC-Apparatus for the detection of gases

II) Directive Européenne DBT 2014/35/UE du 26/02/14: Basse Tension
The European Directive LVD 2014/35/UE dated from 26/02/14: Low Voltage


Normes harmonisées appliquées: **EN 61010-1:10** Règles de sécurité pour appareils
Harmonised applied Standard électriques de mesurage
Safety requirements for electrical equipment for measurement

III) Norme de performance métrologique
Metrology Performance Standard

Normes appliquée
Applied Standard

VDI 2053:04, Annex2,
Mesure du CO (CO measurement)

Organisme certificateur
Certification Body



Rapport d'essai
Test Report

S274 2007 T1

Arras, le 20/04/2016 (April 20th, 2016)

Michel Spellemaeker



Oldham S.A.S.
Z.I. EST - C.S. 20417
62027 ARRAS Cedex – FRANCE
Tel. : +33(0)3 21 60 80 80
www.oldhamgas.com

Global Director of Product Management

UE_CPS_revA



Thank you for reading this data sheet.

For pricing or for further information, please contact us at our UK Office, using the details below.



UK Office

Keison Products,

P.O. Box 2124, Chelmsford, Essex, CM1 3UP, England.

Tel: +44 (0)330 088 0560

Fax: +44 (0)1245 808399

Email: sales@keison.co.uk

Please note - Product designs and specifications are subject to change without notice. The user is responsible for determining the suitability of this product.