

### **Instructions on entering an offset in the R38 controller**

1. Refer to the instruction manual supplied with the oven for the controller button descriptions.
2. Press and hold the P button for 5-6 seconds. SP.1 will be displayed
3. Press the up arrow key until r.P is displayed, then press P to accept.
4. Use the up arrow key and enter number 381, then press P.
5. The display will show 'SPL', which will be flashing
6. Press the down arrow key until CA is displayed and press P. This is the calibration parameter
7. Use the up or down arrow keys to set this to the desired offset value and press P to accept.
8. To exit the configuration mode, no key should be pressed for approx. 20 seconds.

**Please ensure** that no other parameters are adjusted during this procedure, otherwise operation of the oven could be compromised.



Thank you for reading this data sheet.

For pricing or for further information, please contact us at our UK Office, using the details below.



**UK Office**

**Keison Products,**

**P.O. Box 2124, Chelmsford, Essex, CM1 3UP, England.**

**Tel: +44 (0)1245 600560**

**Fax: +44 (0)1245 600030**

**Email: [sales@keison.co.uk](mailto:sales@keison.co.uk)**

Please note - Product designs and specifications are subject to change without notice. The user is responsible for determining the suitability of this product.