

Sintering Furnace - PDS

General Information

The PDS type furnaces are available with a usable volume of 25, 120 and 250 l. With the special design of the PDS type furnaces, it is possible to do both, debinding and sintering in one furnace.

For debinding, a special gas guiding configuration and molybdenum retort are utilized to protect the heating elements from all gaseous by-products. The heating elements and radiation shields are also constructed of molybdenum. The system is surrounded by a double walled, water cooled vessel. To prevent condensation of the byproducts in the gas outlet system, the tubes leading to the afterburner are heated. Debinding is normally performed at a slight overpressure, and upon request, the furnace can be configured for debinding under partial pressure. For partial pressure operation, a special oil pump is integrated into the furnace to pump the gaseous by-products out of the furnace and into the afterburner.

After the debinding step, it is possible to increase the temperature up to 1450 °C for the sintering process. During sintering, a vacuum, partial pressure, or slight overpressure can be applied. The system operation is automated, and therefore, can support the use of Hydrogen up to 100 % purity. A touch panel interface is used for parameter programming and process visualization.

The PDS offers two operation modes. The first mode is manual operation, which consists of manually adjusting all system features. The second mode is automated and allows the user to program the operational parameters of the furnace. Upon initiating automatic operation, the system performs an evacuation step, a leakage test, and an overpressure test. Once all steps have completed successfully, the operating process begins. In the event any malfunctions are detected, the system immediately returns to a safe state, which is especially important when using reactive gases.

Various dosing and controlling devices control all gas operations. The vacuum systems are provided by various pumping stations per the required vacuum levels. The temperature in each of the three heating zones is individually controlled to achieve the best uniformity. The clear advantage of the PDS is the possibility to perform debinding and sintering in a single furnace. Careful design of the vacuum and gas flow guidance system allows the PDS to provide a single solution for the application.

Standard features

- Debinding and sintering in one step
- Debinding in partial pressure possible
- Precisely controlled atmosphere with highest possible purity (6 N or better) for metallic furnaces
- Hydrogen partial pressure upon request
- Precisely controlled vacuum pumping speeds appropriate for use with powders
- Fully automatic operation
- Data recording for quality management



Sintering Furnace - PDS

Technical Specifications

PDS 120 MO/14

Dimensions:	2600 x 2300 x 3000
External H x W x D (mm)	
Transport weight (kg)	4500
Usable space	
Volume (litres)	120
H x W x D (mm)	400 x 400 x 750
Thermal values	
Tmax (°C)	1450
-Delta-T (K)	±5
Cooling time (h)	8
Max. heat-up rate (K/min)	10
Connecting values	
Power (kW)	230
Voltage (V)	400 (3P)
Current (A)	3 x 330
Series fuse (A)	3 x 400
Vacuum	
Leakage (mbar l/s)	
Vacuum range depending on the pumping unit	rough, fine or high vacuum
Cooling water required	
Flow (l/min)	120
Gas supply	
Nitrogen or Argon flow, others on request (l/h)	500-2000
Controller	Siemens



Thank you for reading this data sheet.

For pricing or for further information, please contact us at our UK Office, using the details below.



UK Office

Keison Products,

P.O. Box 2124, Chelmsford, Essex, CM1 3UP, England.

Tel: +44 (0)330 088 0560

Fax: +44 (0)1245 808399

Email: sales@keison.co.uk

Please note - Product designs and specifications are subject to change without notice. The user is responsible for determining the suitability of this product.