



RAE-Sep Tube Data Sheet

Butadiene (Polymer) C₄H₆ No. 012-3024-005

Compound	Butadiene
Standard Lamp	9.8 eV
Typical Range (ppmv)	0.1 - 200
Sample Time (sec)	75
Sample Volume (mL)	550
Total VOC Capacity (ppmv)	150

Temperature Range: 5 - 40°C (41 - 104°F)

Temp (°C)	5-18	18-30	30-40
Temp (°F)	41-64	64-86	86-104
Measure Time (sec)	180	75	50
Sample Vol. (mL)	1500	600	400

Calibration should be performed at the same temperature as the measurement.

Humidity: 0 - 95% RH.

RH	<5%	50%	80%
Correction Factor (CF)	1.0	1.5	1.6

When calibrated from a dry gas cylinder, multiply the reading by the CF to obtain the true value.

Color Change: None

Storage Life and Conditions: Unopened tubes can be stored for 2 years in darkness at 0 - 40°C (32 - 104°F). Open tubes may be stored for up to 8 hours in clean air without significant loss of capacity.

Note: For more details on tube operation see Technical Note 147.

Caution: Dispose of spent or expired tubes according to local regulations. Used tubes may contain toxic chemicals absorbed from the test environment. Unused tubes contain no hazardous or leachable materials.

Cross-sensitivity:

Substance	Test Conc. (ppmv)*	Apparent Butadiene Response
Acrylonitrile	100	0.0
Styrene	100	0.0
Ethylbenzene	200	0.0
Toluene	100	0.2
Toluene	200	2
Benzene	10	0.3
Benzene	100	7
Methane	25000**	0.0
Methyl Bromide#	5	3#
Propane	1000	0.0
Isobutane	100	0.0
Isobutylene	50	40
n-Hexane	200	0.0
Cyclohexane	50	0.5
Vinyl Chloride##	40	17
1,2-Dichloroethane	40	0
Vinylidene Chloride	40	20
Trichloroethylene	40	0
Perchloroethylene	40	0

*Not necessarily the maximum allowable conc.

** Methane above 1% by volume reduces the PID response, but has no effect on tube capacity. Butane and higher hydrocarbons reduce tube capacity.

Methyl bromide can be measured using a 10.6 eV lamp and a 60 sec. sampling time at room temperature. Adjust time at other temperatures proportionately.

Vinyl chloride can be measured using a 10.6 eV lamp and a 30 sec. sampling time at room temperature. Adjust time at other temperatures proportionately. 1,2-DCA, TCA, TCE, and PCE do not interfere. 1,1-DCE gives about a 30% cross-sensitivity to the vinyl chloride measurement.



Thank you for reading this data sheet.

For pricing or for further information, please contact us at our UK Office, using the details below.



UK Office

Keison Products,

P.O. Box 2124, Chelmsford, Essex, CM1 3UP, England.

Tel: +44 (0)1245 600560

Fax: +44 (0)1245 600030

Email: sales@keison.co.uk

Please note - Product designs and specifications are subject to change without notice. The user is responsible for determining the suitability of this product.