# Environma **6000** Precision Headspace Analysers Stion Analysing

nentation

ency Ultraviolet Gas Production owdered Metals d Environments

s Manufacturing

Carbon Refining Food Packaging s ■ Glove Boxes on Beam ■ R & D ■ Fermentation

d Environments Manufacturing ssel Blanketing

tion Analysing ncy Ultraviolet Gas Production Ndered Metals Environments anufacturing el Blanketing

S Production

ered Metals

ve Boxes

; Production



# Advanced Products for Measurement of O<sub>2</sub> and CO<sub>2</sub> in MAP/CAP Headspace Atmospheres



# **Applications**

Fresh Meat Cooked Meat Vegetables Salads Snack Foods Ready Meals Fish Bakery Pharmaceutical Vials Pharmaceutical Packaging

#### Features & Benefits

- Easy to set up and use
- Intuitive menu
- Auto calibrate
- Auto diagnosis

- Set tests for pass or fail
- Printer option
- Computer software option
- Waterproof option

Environments lanufacturing sel Blanketing tion Analysing ncy Ultraviolet Gas Production owdered Metals d Environments Manufacturing Carbon Refining Food Packaging ■ Glove Boxes n Beam ■ R & D Fermentation d Environments Manufacturing isel Blanketing tion Analysing cy Ultraviolet as Production dered Metals nvironments anufacturing l Blanketing n Analysing Ultraviolet Production red Metals facturing **Jltraviolet** 

The Systech 6000 range offers three different models to accommodate your oxygen and carbon dioxide measurements.

The compact enclosure maximizes space on carts and table tops. Seamless cover design and polycarbonate operator's panel sheds spills and resists most chemicals and solvents.

6500 measures oxygen levels only



**6600** measures both oxygen and carbon dioxide concentrations.



6700 measures carbon dioxide only



Systech Instruments is recognised worldwide for its line of precision trace oxygen and carbon dioxide analysers. The Systech 6000 headspace analysers offer high levels of performance technology and operator ease to fulfill the latest industry demands for accuracy and reliability.

These highly advanced instruments are equipped with integral sampling systems, unique miniature zirconia and infrared sensors, and microprocessor control to deliver the most accurate and repeatable performance possible. One touch automated calibration and product analysis make these analysers easy to use.

Rugged and compact epoxy clad cabinetry, seamless operator's console and no-compromise engineering make these instruments ideal for both the laboratory or the demanding climate of the production floor.

#### **RS232 output**

RS232 output prints product description and sample data to 40 column thermal desktop printer for hard copy of calibration and test results. Prints test "Fail" according to user defined alarm settings.



#### **Unique sensors**

Analysis of small sample volumes. Response is typically less than five seconds for oxygen and ten seconds for carbon dioxide. Internal microprocessor manages calibration, autoranging, pump speed and duration, time and date, outputs, and many other functions to ensure consistent, error-free results.

# **Precision flowmeter**

Precision flowmeter provides visual confirmation of sample flow. Unlike warning lights, users can monitor system performance and resolve potential problems before they occur.

#### **Display hold**

Locks most recent high or low concentration value. Bright, large character display is easy to read in any lighting condition. Status lights indicate mode of operation.

#### **Timed Analysis**

Timed, automatic analysis is provided at the touch of a button. Programmable sampling duration and data integration make these among the most advanced headspace analysers available.

#### **Autocalibration**

With a single button the instrument self calibrates in just 30 seconds using ambient air



#### Sample probe

The robust sample probe is designed to accept standard luer accessories and includes easily replaced needles and particulate filters. With a convenient sample probe holder to prevent needle contamination and sample line damage.

#### Software

User friendly software parameters are easy to enter and can be secured against accidental change.



#### **Automated sampling**

Automated package sampling is easy. Insert the sampling needle into the package and press analyse. The instrument does the rest; extracting the sample, analysing sensor output and holding the results for viewing on the bright autoranging display.

## Samples injected directly

Headspace samples can be injected directly into the instrument when automated sampling is not practical.

#### Accessories

The can piercing station is perfect for rigid packaging and has proven to be stable and reliable in hundreds of demanding applications.



**Can Piercing Station** 

. ci oile ontact Leng inealing ■ V amics Comb Oxygen Defi s **=** High Puri ■ Alloys and lity ■ Control I ■ Contact Le keting ■ Hyd n Analysing ass/Fibre Opt uction ■ Elect wdered Metal ity ■ Control ■ Contact Ler Annealing ■ \ ramics Comb Oxygen Defici ■ High Purity Alloys and Pa ■ Controlled ontact Lens aling ■ Ves s Combust n Deficien h Purity G s and Pow ntrolled Er tics G als ■ Fe ■ Vesse

ombustio

Deficienc

Purity G

# **Principle of operation**

#### Oxygen

The oxygen detector utilises a high purity, stabilised zirconia ceramic and platinum sensor maintained within a high temperature environment. The sensor produces a log output which is converted and linearised to yield a digital readout directly proportional to a sample's oxygen content.

#### **Carbon Dioxide**

This sensor integrates a solid state infrared source and detector into a single high performance assembly. Narrow wavelength filtering and strict temperature compensation ensure that only carbon dioxide is measured, even within complex gas mixtures. Precise signal conditioning and microprocessor control provide direct digital indication of CO<sub>2</sub> concentrations.

#### **Technical Specifications**

Oxygen Range Autoranging from 0.001 to 100% (models 6500 & 6600)

Carbon Dioxide Range Autoranging from 0.1 to 100% (models 6600 & 6700)

Displays Bright 4 Digit LED, Display Hold, Analyse, and Calibration Status

Indicators

Response Time <5 seconds  $(O_2)$ , <10 seconds  $(CO_2)$ 

Accuracy O2 Below 10% = 0.02% absolute (max 2% of reading) and ±1 on the

last digit shown

Above 10% = 0.2% absolute (max 2% of reading) and  $\pm 1$  on the

last digit shown

Accuracy CO2 ±2% FSD

Ambient Temperature +5 to +40°C

Internal Sample Pump Processor Controlled Diaphragm Type

Syringe Injection Via Male Luer Syringe Adaptor (supplied)

Enclosure Epoxy Coated Steel, Polycarbonate Operators Panel

Dimensions 305mm W x 254mm D x 152mm H

Weight 5.3 kg

#### **Options**

Computer Interface RS232 Port for Computer/Data Printer

Rigid Pack Sampler Extracts samples from cans, jars, bottles, etc.

Includes all necessary fittings and supplies.

Compact Printer 40 Column Thermal Desktop Printer

#### **Power Requirements**

Mains power 110 / 220 VAC, 50 / 60 Hz. 100 Watt Maximum

Systech Instruments have over 25 years experience of providing analysis solutions for a wide range of industries. From our manufacturing plant in the UK we produce gas analysers for industrial process industries, headspace analysers for monitoring gas flushing of food products, and our range of permeation analysers.

pallouried ontact Lens I inealing ■ Ve amics Combu Oxygen Defici s 
High Purity ■ Alloys and P lity ■ Controlle I ■ Contact Len keting ■ Hydro on Analysing **•** ass/Fibre Optic uction ■ Electro Ndered Metals ity ■ Controlle ■ Contact Lens Annealing ■ Ve ramics Combus Oxygen Deficie ■ High Purity Alloys and Pov ■ Controlled | ontact Lens M aling ■ Vesse cs Combustic n Deficiency h Purity Gas and Powd ntrolled Env ydrocarbo



Thank you for reading this data sheet.

For pricing or for further information, please contact us at our UK Office, using the details below.

UK Office Keison Products,

P.O. Box 2124, Chelmsford, Essex, CM1 3UP, England.

Tel: +44 (0)330 088 0560

Fax: +44 (0)1245 808399

Email: sales@keison.co.uk

Please note - Product designs and specifications are subject to change without notice. The user is responsible for determining the suitability of this product.